

Lutz Drum Pumps and Flow Meters for the Food, Pharmaceutical and Cosmetics Industry

Certified Solutions

NEW: Eccentric Screw Pumps B70V SanitaryPlus



NEW



Safety is our Concern

Lutz Pumps and Flow Meters for the Food, Pharmaceutical and Cosmetics Industry

During food production, raw materials and finished food products come into contact with various objects and materials, and must be suitable for this. This also includes devices and machine parts for commercial food production. These are defined as "food contact materials" and are specified in food product legislation.



Regulation (EC) 1935/2004

Pumps and flow meters in contact with food products are also considered to be food contact materials and are thus subject to strict legal regulations. In accordance with EU Regulation no. 1935/2004, these are to be produced in accordance with good manufacturing practice and may not release substances which pose a hazard to the health, cause unacceptable changes to the food products or impair their odour or taste. Lutz drum pumps, flow meters and accessories meet the requirements of Regulation (EC) 1935/2004 and bear the "glass and fork" symbol to indicate their suitability for foodstuffs. The associated Regulation (EC) 10/2011 on plastics in contact with foodstuffs lists the migration values of chemicals which may not be exceeded in defined reagent tests.



FDA Approval

The Food and Drug Administration in the USA certifies materials and substances and also defines limit values for extractable substances which must be complied with, as is the case with elastomers for aqueous or fatty food products (21 CFR 177.2600).



USP – U.S. Pharmacopeial Convention

The United States Pharmacopeial Convention, Inc. is a scientific nonprofit organization that sets standards for the identity, quality, and purity of medicines, food ingredients, and dietary supplements manufactured, distributed, and consumed worldwide. It provides documentary standards and reference materials to help manufacturers, suppliers, and regulators to safeguard the dietary supplement supply, and limit adulterants and contaminants.



3-A Sanitary Standard

Beyond the safety of the materials used, the 3-A Sanitary Standard places stringent design requirements calling for a hygienically flawless and easy-to-clean design. The new Lutz B70V SanitaryPlus pumps consistently meet the requirements for hygienic design and are certified in accordance with the current version of the "3-A Sanitary Standards for Centrifugal and Positive Rotary Pumps" and are thus equipped for the international market.

Lutz B70V SanitaryPlus pumps are consistently designed with manually detachable, threadless connections in areas coming into contact with liquids. They are quick and easy to dismantle for thorough cleaning and disinfection by hand or with tools such as a water stream or cleaning machines. All products covered in the product are easily accessible and visible.



ATEX Directive

Pumps and flow meters from the PURE and Sanitary series are also available in an explosion-proof version in accordance with ATEX Directive 2014/34/EU. They are well-suited for pumping highly flammable liquids in food and beverage production, such as alcohols, essential oils and flavourings, as well as cleaning products and disinfectants used for cleaning purposes.

The Production Range at a Glance



Eccentric Screw Pumps **Lutz B70V SanitaryPlus**

- + Hygienically designed according to the latest 3-A standards
- + Easily accessible and inspectable components
- + Thread-free, manually detachable quick connections
- + Polished metal surface
- + Quick to dismantle, easy to clean
- + Also for alcoholic food products, cosmetics and pharmaceuticals and flammable cleaning products
- + For liquid foodstuffs and luxury foodstuffs, pharmaceutical substances and cosmetic products



**Eccentric Screw Pumps
Lutz B70V SanitaryPlus**
Page 4-15

Suitable Accessories
Page 48-53



Pumps and Flow Meters in **PURE Version**

- + Physiologically safe type
- + High surface quality
- + Food-safe connections
- + Also for alcoholic food products, cosmetics and pharmaceuticals and flammable cleaning products



**Pumps and Flow Meters
in Pure Version**
Page 16-47

Suitable Accessories
Page 54-59



Lutz B70V SanitaryPlus

Designed according to the latest standards for high demands of the food-, pharmaceutical and cosmetics industry

When using hygienic pumps, the operator expects besides a high system availability and low maintenance requirement an absolutely perfect hygienic and easy to clean design. The B70V SanitaryPlus here sets new standards with its one-piece joint-free drive shaft and consistently without threads in the hydraulic area. Only a few components reduce the assembly and dismantling times as well as the cleaning effort for approx. 80%.

Our commitment:

To satisfy the high criteria and demands set by standards



Hygienic aspect:

Consequently realized

The new eccentric screw pump Lutz B70V SanitaryPlus was developed and designed for pumping liquid foodstuffs, pharmaceutical agents and cosmetic products from different vessels and containers. This new development strictly meets the constructive requirements of the hygienic design and is certified and approved according to the latest "3-A Sanitary Standards".

Benefits of the Lutz B70V SanitaryPlus

- No-thread-design in the hydraulic area
- One-piece drive shaft for perfect hygiene
- Long operating times due to contamination-proof and sterile pump design
- Delivery volume proportional to speed
- Temporary reversible conveying direction
- Continuous and low pulsation pumping, nearly independent from pressure- and viscosity fluctuations
- Stable suction- and pressure capacities
- Service-friendly
- Housing design, free of dead space for good flow properties
- Wetted surfaces with a polished finish prevent the accumulation of liquid and facilitate the cleaning

Versatile and variable:

With a flow rate of 12 to 50 l/min and an operating pressure of max. 10 bar, the Lutz B70V SanitaryPlus hygienic pump is suitable for pumping thin-bodied to highly viscous media.

The chosen immersion depth and the small immersion tube diameter ensure that drums, IBC containers and other commercially available containers are emptied safely and almost completely without residue from the top.



Lutz Eccentric Screw Pumps

Characteristics and Construction

All areas coming into contact with the liquid being pumped are equipped with manually detachable, non-threaded connections. The design is almost free of dead space, thus microbiological problems caused by germs and bacteria are practically impossible.

Quick cleaning

For a fast and thorough cleaning and disinfection by hand or mechanically by means of water jets or cleaning machines, the Lutz B70V SanitaryPlus can be quickly and easily dismantled. All parts coming into contact with the liquid are easy accessible for inspection and service. This pump is a solution for application cases where the use of a CIP pump is technically impossible.

All parts coming into contact with the product are made of resistant stainless steel (1.4404/1.4462/1.4571), 3-A/FDA compliant plastics (PTFE) and elastomers (EPDM).



Jetzt
Produktvideo
ansehen!



Lutz B70V SanitaryPlus

Just a few components – minimum wear and fast to clean



4

Improvement of anti-twist protection

Easy and fault-free assembly of the pump without special tools



5

Housing design free of dead space

Microbiological problems caused by germs and bacteria are therefore practically impossible



6

No-Thread-Design

One-piece drive shaft for perfect hygiene

High application possibility

The pump covers a wide range of applications in the Food- and Pharma- Industry due to the certification.

The user-friendly design and the easy cleaning make the pump very interesting for the chemical industry where requirements of the applications often change and therefore an easy cleaning is required.

1

Smooth surface

Fast to clean (less than Ra 0,8 at product contacted surfaces) and thus protection of bacterial contamination

2

Improved stator fixing

Easy assembly and change of the stator with locking pin and anti-twist protection

3

Tri-Clamp connections

Hygienic and user-friendly Tri-Clamp connections acc. to DIN 32676 for easy assembly



Function

An impulse transmitter transfers magnetic impulses of the rotating motor shaft contact-free to the impulse sensor. The measured impulses are evaluated in the Lutz operating unit BE10 and appear on the display by means of the pre-determined calibration factor as transferred flow quantity.

Hygienic and without wear:

Contact-free flow measurement

For the Lutz eccentric screw pumps a lifting device with integrated impulse sensor for indirect flow measurement was developed. The contact-free mode of measurement is very interesting for hygienic applications in the food-, pharmaceutical- and cosmetics industry, as well as for industrial applications with viscous, adhesive and solid containing liquids.

The time-consuming cleaning process of the flow meter system is not necessary and as experience has shown, conventional volumetric flow meters quickly come in these circumstances to their limit, while other measuring methods are often very complex and/or are not suitable for mobile use.

The contact-free, indirect mode of measurement with impulse sensor from Lutz is a hygienic, wear-free and reliable option without direct contact with the liquid being pumped.

Features and Benefits

- Compact and easy to handle unit for maximum mobility
- All live-/data elements on the motor-/lifting-device unit
- Pump tube can be detached from motor-/lifting-device with a quick-action coupling
- Pump tube without electronic components enables a thorough cleaning and disinfection also by means of water jets or in cleaning machines
- Easy handling and control with the Lutz operating unit with touch screen display and menu-navigation in plain text
- Can be combined with relay module RM10 and other modules of the Lutz flow meter programme

**Order instructions for
contact-free flow measurement**

Page 60-61





B70V-H-SR SanitaryPlus 12.1, 25.1 and 50.1

for viscosities up to 30,000 mPas

Materials (coming into contact with the pumped medium):

Version:	B70V-H-SR SanitaryPlus 12.1/25.1/50.1
Housing:	SS (1.4404)
Rotor/Shaft:	SS (1.4571, 1.4462)
Seals:	EPDM, FPM
Mechanical seal:	SiC/carbon/EPDM (FPM), optional SiC/SiC/EPDM (FPM)
Stator material:	PTFE, EPDM (Size 50.1)



Lutz Eccentric Screw Pumps

B70V-H-D SanitaryPlus 12.1, 25.1

Product detail



Pump tube		B70V-H-D SanitaryPlus	
Size		12.1	25.1
Seal	Mechanical seal (MS)	MS	MS
Delivery rate*	up to l/min.	12	25
Delivery head*	up to bar	6	8
Temp. of medium	max. °C	100	100
Material outer tube		1.4404	1.4404
Immersion tube diameter	mm	54	54
Pressure joint	Tri-Clamp	DN 50	DN 50
Weight	kg	8	8
Length**	mm	1100	1100
Stator PTFE	Order-No.	0172-094	0172-194
Seal FPM		●	●
Stator PTFE	Order-No.	0172-044	0172-144
Seal EPDM		●	●

* Determined with water at 20 °C, three-phase motor (900 rpm)

** Special length on request

- Explosion proof eccentric screw pump approved category 1 / 2 (acc. to ATEX) for pumping flammable liquids of the explosion group IIB (B70V-H) and temperature class T4 at 40 °C ambient temperature or temperature class T3 at 60 °C ambient temperature



Choice of motors



Three-phase motors
230/400 V, 50 Hz,
RAL 9005,

Energy efficiency class
IE 3 in accordance
with EU regulations
640/2009 and 04/2014.

Sonderspannungen,
Frequenzen, Schutz-
arten auf Anfrage.

Motors with protection switch	For B70V-H-D SanitaryPlus - 12.1		For B70V-H-D SanitaryPlus - 25.1	
Type	0.37 kW 700 1/min.	0.55 kW 900 1/min.	0.55 kW 700 1/min.	0.75 kW 900 1/min.
Protection class/Weight	IP 54 16 kg	IP 54 12 kg	IP 54 16 kg	IP 54 22 kg
Order-No.	0172+802	0172+805	0172+808	0172-900

Motore, explosionsgeschützt	For B70V-H-D SanitaryPlus - 12.1		For B70V-H-D SanitaryPlus - 25.1	
Type	0.37 kW, 700 1/min.	0.55 kW, 900 1/min.	0.55 kW, 700 1/min.	0.65 kW, 900 1/min.
Type of protection	II 2 G Ex e II T3	II 2 G Ex e II T3	II 2 G Ex e II T3	II 2 G Ex e II T3
Protection class/Weight	IP 55 19 kg	IP 55 17 kg	IP 55 22 kg	IP 55 20 kg
Order-No.	0172-801	0172-804	0172-807	0172-810

Motors with frequency converter	For B70V-H-D SanitaryPlus - 12.1		For B70V-H-D SanitaryPlus - 25.1	
Type	0.55 kW, 0-900 1/min.		0.55 kW, 0-900 1/min.	0.75 kW, 0-900 1/min.
Protection class/Weight	IP 55 16 kg		IP 55 16 kg	IP 55 22 kg
Order-No.	0172-769		0172-769	0172-768

Motors with cable terminal box	For B70V-H-D SanitaryPlus - 12.1		For B70V-H-D SanitaryPlus - 25.1	
Type	0.37 kW, 700 1/min.	0.55 kW, 900 1/min.	0.55 kW, 700 1/min.	0.75 kW, 900 1/min.
Protection class/Weight	IP 54 16 kg	IP 55 12 kg	IP 55 16 kg	IP 55 22 kg
Order-No.	0172+803	0172+806	0172+809	0172-901

B70V-H-D SanitaryPlus 12.1, 25.1



for viscosities up to 100,000 mPas

Materials (coming into contact with the pumped medium):

Version:	B70V-H-D SanitaryPlus 12.1/25.1
Housing:	Stainless steel (1.4404)
Rotor/Shaft:	Stainless steel (1.4571, 1.4462)
Seals:	EPDM
Mechanical seal:	SiC/carbon/EPDM (FPM), optional SiC/SiC/EPDM (FPM)
Stator material:	PTFE, EPDM (Size 50.1)






Equipped with mounting strap and motor quick coupling as standard.



Lutz Eccentric Screw Pumps

B70V-H-D SanitaryPlus 25.2, 50.1, 75.1

Product detail		B70V-H-D SanitaryPlus			
	Size	25.2	50.1	75.1	
	Seal Mechanical seal (MS)	MS	MS	MS	
	Delivery rate* up to l/min.	25	50	75	
	Delivery head* up to bar	10	8	6	
	Temp. of medium max. °C	100	100	100	
	Material outer tube	1.4404	1.4404	1.4404	
	Immersion tube diameter mm	54	54	54	
	Pressure joint Tri-Clamp	DN 50	DN 50	DN 50	
	Weight kg	8	8	8	
	Length** mm	1100	1100	1100	
	Stator EPDM Seal EPDM	Order-No. –	0172-548	–	
	Stator PTFE Seal FPM	Order-No. 0172-294	0172-594	0172-584	
	Stator PTFE Seal EPDM	Order-No. 0172-244	0172-544	0172-554	
<p>* Determined with water at 20 °C, three-phase motor (900 rpm) **Special length on request</p> <p>● Explosion proof eccentric screw pump approved category 1 / 2 (acc. to ATEX) for pumping flammable liquids of the explosion group IIB (B70V-H) and temperature class T4 at 40 °C ambient temperature or temperature class T3 at 60 °C ambient temperature</p>					
					
Choice of motors					
	Motors with protection switch		For B70V-H-D SanitaryPlus - 25.2 and 50.1		For B70V-H-D SanitaryPlus - 75.1
	Type	0.75 kW 700 1/min.	1.1 kW 700 1/min.	1.1 kW 900 1/min.	1.5 kW 700 1/min. 1.5 kW 900 1/min.
	Protection class/Weight	IP 54 18 kg	IP 54 22 kg	IP 54 34 kg	IP 54 34 kg IP 54 34 kg
	Order-No.	0172+814	0172+825	0172-902	0172-760 0172-904
	Motore, explosionsgeschützt		For B70V-H-D SanitaryPlus - 25.2 and 50.1		For B70V-H-D SanitaryPlus - 75.1
	Type	0.65 kW, 700 1/min.	1.0 kW, 900 1/min.	1.3 kW, 900 1/min.	1.9 kW, 900 1/min.
	Type of protection	II 2 G Ex e II T3	II 2 G Ex e II T3	II 2 G Ex e II T3	II 2 G Ex e II T3
	Protection class/Weight	IP 55 27 kg	IP 55 23 kg	IP 55 40 kg	IP 55 52 kg
	Motors with frequency converter		For B70V-H-D SanitaryPlus - 25.2 and 50.1		For B70V-H-D SanitaryPlus - 75.1
	Type	0.75 kW 0-900 1/min.	1.1 kW 0-900 1/min.	1.5 kW, 0-900 1/min.	
	Protection class/Weight	IP 55 22 kg	IP 55 25 kg	IP 55 37 kg	
	Order-No.	0172-768	0172-767	0172-766	
	Motors with cable terminal box		For B70V-H-D SanitaryPlus - 25.2 and 50.1		For B70V-H-D SanitaryPlus - 75.1
	Type	0.75 kW 700 1/min.	1.1 kW 700 1/min.	1.1 kW 900 1/min.	1.1 kW 700 1/min. 1.5 kW 700 1/min. 1.5 kW 900 1/min.
	Protection class/Weight	IP 55 18 kg	IP 55 22 kg	IP 55 34 kg	IP 55 22 kg IP 55 34 kg IP 55 34 kg
	Order-No.	0172+815	0172+826	0172-903	0172+826 0172-761 0172-905

Three-phase motors
230/400 V, 50 Hz,
RAL 9005,
Energy efficiency class
IE 3 in accordance
with EU regulations
640/2009 and 04/2014.
Sonderspannungen,
Frequenzen, Schutz-
arten auf Anfrage.

B70V-H-D SanitaryPlus 25.2, 50.1, 75.1



for viscosities up to 100,000 mPas

Materials (coming into contact with the pumped medium):

Version:	B70V-H-D SanitaryPlus 25.2/50.1/75.1
Housing:	Stainless steel (1.4404)
Rotor/Shaft:	Stainless steel (1.4571, 1.4462)
Seals:	EPDM
Mechanical seal:	SiC/carbon/EPDM (FPM), optional SiC/SiC/EPDM (FPM)
Stator material:	PTFE, EPDM (Size 50.1)



Equipped with mounting strap and motor quick coupling as standard.



Lutz Drum and Container Pumps in PURE Version

Pumps and flow meters in contact with food products are considered to be "food contact materials" and are thus subject to strict legal regulations. The new Lutz PURE series includes products which are in conformity with the ATEX Directive as well as with the FDA Approval and the European Regulation according to 1935/2004/EC.



Lutz Drum Pumps SS 41 in PURE Version

A versatile and variable drum pump ideal for corrosive and neutral, aqueous to slightly viscous fluids in the production and processing of food products.

- + Low weight, easy handling
- + Completely dismantable and cleanable
- + Two impeller forms for flow rate as required
- + Mechanically sealed (MS) version suitable for crystallizing and adhesive liquids, as well as liquids containing solids
- + Not filled with lubricants, preventing product contamination
- + Sealless version (SL) is suitable for limited dry running



Properties:

- Materials in contact with liquids in food quality
- Shaft seal: Mechanically sealed (MS) or sealless (SL)
- Lutz hand wheel for quick motor assembly/disassembly and as carry handle
- Optionally available with electrical drive with stageless speed controller
- Explosion-proof versions approved in accordance with the ATEX Directive 2014/34/EU Category 1/2

Lutz Complete Drum Drainage Pumps and Mixing Pumps RE SS 41 and MP SS 41 in PURE Version

Lutz RE complete drum drainage pumps allow you to remove selected raw materials and valuable food products from drums and containers leaving virtually no residue.

- + Maximum pump utilisation and reduced drum cleaning effort
- + Completely dismantable and cleanable
- + Optimized complete drum drainage with a remaining residual quantity of approx. 0.1 liter
- + No leakage when the pump is turned over or at an inclined position
- + Also suitable for crystallizing and adhesive liquids, as well as liquids containing solids
- + Sealing mechanism in pump foot
- + Not filled with lubricants, preventing product contamination



Lutz MP mixing pumps combine the function of agitator and pump in a single device. They are specifically developed for mixing and pumping food products which tend to form sediment after long periods of standing and must be homogenised before being processed.

- + Agitator and pump in a single device
- + Can change function during ongoing operation without having to be switched
- + High mixing performance and flow rate for thorough homogenisation and rapid drainage
- + Completely dismantable and cleanable
- + Also suitable for crystallizing and adhesive liquids, as well as liquids containing solids
- + Mixing apertures in the outer pipe can be opened and closed using a lever below the hand wheel
- + Not filled with lubricants, preventing product contamination







Properties:

- Materials in contact with liquids in food quality
- Lutz hand wheel for quick motor assembly/disassembly and as carry handle
- Optionally available with electrical drive with stageless speed controller
- Explosion-proof versions approved in accordance with the EX Directive 2014/34/EU Category 1/2




Lutz Drum and Container Pumps

Pump tube SS PURE (stainless steel) for aqueous and fatty foodstuffs

Product detail		Pump tube		SS-SL		SS-MS		
	Type of impeller			L	R	L	R	
	Category 1 / 2 (acc. to ATEX)			no	no	yes	yes	
	Immersion tube diameter:	up to mm		41	41	41	41	
	Temperature of medium:	up to °C		100	100	100	100	
	Material:	Pump tube	1.4571	1.4571	1.4571	1.4571		
		Impeller	PP	SS	ETFE	ETFE		
	Hose connection:	Tri-Clamp DN	32	32	32	32		
	Length: 700 mm*** ▲	Order No. basic pump	0150-003	0150-000	0151-003	0151-000		
	Length: 1000 mm*** ▲	Order No. basic pump	0150-004	0150-001	0151-004	0151-001		
	Length: 1200 mm*** ▲	Order No. basic pump	0150-005	0150-002	0151-005	0151-002		
Version: PURE SL ▲		Order No. additional price	0150-350	0150-351	–	–		
Version: PURE MS FPM ▲		Order No. additional price	–	–	0151-350	0151-351		
Version: PURE MS EPDM ▲		Order No. additional price	–	–	0151-352	0151-353		
▲ Please choose Order-No. basic pump + Order-No. PURE additional price								
Choice of motors				Operating data				
	MI 4	MI 4-E		Characteristic curve no.	401	400	401	400
	–	with speed controller		Flow rate* up to l/min.	117	210	117	210
	Output: 500 W	500 W		Delivery head* up to m wc	19	10	19	10
	Voltage: 230 V	230 V		Viscosity** up to mPas	500	350	500	350
				Density**** up to kg/dm³	1,4	1,1	1,4	1,1
	Order No. 0030-000	0030-001		Weight (kg) Motor + pump tube	5,7	5,7	5,7	5,7
	MA II 3			Characteristic curve no.	403	402	403	402
	Output: 460 W	460 W		Flow rate* up to l/min.	95	178	95	178
	Voltage: 230 V	230 V		Delivery head* up to m wc	14	9	14	9
	LVR.: no	yes		Viscosity** up to mPas	350	200	350	200
				Density**** up to kg/dm³	1,6	1,2	1,6	1,2
	Order No. 0060-000	0060-008		Weight (kg) Motor + pump tube	7,5	7,5	7,5	7,5
	MA II 5	MA II 5	MA II 5 S	Characteristic curve no.	405	404	405	404
	Output: 575 W	575 W	575 W	Flow rate* up to l/min.	100	190	100	190
	Voltage: 230 V	230 V	230 V	Delivery head* up to m wc	16	10	16	10
	LVR.: no	yes	no	Viscosity** up to mPas	700	550	700	550
		acid-proof	Density**** up to kg/dm³	1,8	1,3	1,8	1,3	
Order No. 0060-001	0060-009	0060-091	Weight (kg) Motor + pump tube	8,3	8,3	8,3	8,3	
	MA II 7			Characteristic curve no.	407	406	407	406
	Output: 795 W	795 W		Flow rate* up to l/min.	115	210	115	210
	Voltage: 230 V	230 V		Delivery head* up to m wc	20	13	20	13
	LVR.: no	yes		Viscosity** up to mPas	500	400	500	400
				Density**** up to kg/dm³	1,9	1,4	1,9	1,4
	Order No. 0060-002	0060-010		Weight (kg) Motor + pump tube	9,5	9,5	9,5	9,5
	B4/GT			Characteristic curve no.	411	410	411	410
	Output: 750 W	750 W		Flow rate* up to l/min.	100	180	100	180
	Voltage: 230/400 V	230/400 V		Delivery head* up to m wc	12	13	12	13
	Protection			Viscosity** up to mPas	500	400	500	400
switch: no	yes		Density**** up to kg/dm³	2,2	2,0	2,2	2,0	
Order No. 0004-050	0004-052		Weight (kg) Motor + pump tube	14,7	14,7	14,7	14,7	

Low-voltage release (LVR): Prevents the pump from starting up again without warning after a power failure. It is recommended when pumping hazardous liquids.



* Determined with water at 20 °C

** Determined with oil

*** Special lengths

200–2500 mm on request

**** Determined with 3 m hose 3/4" and open nozzle 3/4".
Higher densities possible for shorter operating periods.



Special voltages and frequencies on request.

Pump tube SS PURE (stainless steel)

for aqueous and fatty foodstuffs

Materials (coming into contact with the pumped medium):

Version:	SL-R	SL-L	MS-FPM	MS-EPDM
Housing:	SS (1.4571)	SS (1.4571)	SS (1.4571)	SS (1.4571)
Impeller:	SS (1.4571)	PP	ETFE	ETFE
Seals:	none	none	FPM	EPDM
Mechanical seals:	none	none	Carbon, Ceramic, PTFE, SS (1.4571), HC-4 (2.4610)	Carbon, Ceramic, PTFE, SS (1.4571), HC-4 (2.4610)
Bearing:	Pure Carbon	Pure Carbon	Pure Carbon	Pure Carbon
Drive shaft:	SS (1.4571)	SS (1.4571)	SS (1.4571)	SS (1.4571)



Please remember that the flow rate is reduced as the **Viscosity** increases. The **Density** of the pumped liquid similarly affects the flow rate, though to a lesser extent.



Illustration shows:
Pump tube SS MS PURE
with motor MA II



Pump tube also available in PURE version with Tri-Clamp connection. All materials coming into contact with the pumped medium are physiologically safe. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.


Dimension C

Utilisable Length (Dimension C - 40 mm)



Lutz Drum and Container Pumps



Pump tube SS PURE (stainless steel) for alcoholic, highly flammable foodstuffs

Product detail		Pump tube	SS-MS	
	Type of impeller		L	R
	Category 1 / 2 (acc. to ATEX)		yes	yes
	Immersion tube diameter:	up to mm	41	41
	Temperature of medium:	up to °C	100	100
	Material:	Pump tube Impeller	1.4571 ETFE	1.4571 ETFE
	Hose connection:	Tri-Clamp DN	32	32
	Length: 700 mm*** ▲	Order No. basic pump	0151-003	0151-000
	Length: 1000 mm*** ▲	Order No. basic pump	0151-004	0151-001
	Length: 1200 mm*** ▲	Order No. basic pump	0151-005	0151-002
	Version: PURE FPM ▲	Order No. additional price	0151-350	0151-351
	Version: PURE EPDM ▲	Order No. additional price	0151-352	0151-353

▲Please choose Order-No. basic pump + Order-No. PURE additional price

Choice of motors

Operating data

ME II 3		Characteristic curve no.	453	452
Output:	460 W 460 W	Flow rate* up to l/min.	95	178
Voltage:	230 V 230 V	Delivery head* up to m wc	14	9
LVR.: yes	no	Viscosity** up to mPas	350	200
		Density**** up to kg/dm³	1,6	1,2
Order No.	0050-000 0050-016	Weight (kg) Motor + pump tube	8,7	8,7
ME II 5		Characteristic curve no.	455	454
Output:	580 W 580 W	Flow rate* up to l/min.	100	190
Voltage:	230 V 230 V	Delivery head* up to m wc	16	10
LVR.: yes	no	Viscosity** up to mPas	700	550
		Density**** up to kg/dm³	1,8	1,3
Order No.	0050-001 0050-017	Weight (kg) Motor + pump tube	9,6	9,6
ME II 7		Characteristic curve no.	457	456
Output:	795 W 795 W	Flow rate* up to l/min.	115	210
Voltage:	230 V 230 V	Delivery head* up to m wc	20	13
LVR.: yes	no	Viscosity** up to mPas	500	400
		Density**** up to kg/dm³	1,9	1,4
Order No.	0050-002 0050-018	Weight (kg) Motor + pump tube	10,8	10,8
ME II 8		Characteristic curve no.	459	458
Output:	930 W 930 W	Flow rate* up to l/min.	123	243
Voltage:	230 V 230 V	Delivery head* up to m wc	26	15
LVR.: yes	no	Viscosity** up to mPas	750	650
		Density**** up to kg/dm³	1,9	1,4
Order No.	0050-042 0050-041	Weight (kg) Motor + pump tube	10,8	10,8

Low-voltage release (LVR):

Prevents the pump from starting up again without warning after a power failure. Compulsory for explosive areas, in case no special measures are taken (e.g. remote control).

Low-voltage release (LVR):
Prevents the pump from starting up again without warning after a power failure. Compulsory for explosive areas, in case no special measures are taken (e.g. remote control).

* Determined with water at 20 °C

** Determined with oil

*** Special lengths
200–2500 mm on request

**** Determined with 3 m hose 3/4" and open nozzle 3/4".
Higher densities possible for shorter operating periods.



Special voltages and
frequencies on request.

Pump tube SS PURE (stainless steel)


for alcoholic, highly flammable foodstuffs

Materials (coming into contact with the pumped medium):

Version:	MS-FPM	MS-EPDM
Housing:	stainless steel (1.4571)	stainless steel (1.4571)
Impeller:	ETFE	ETFE
Seals:	FPM	EPDM
Mechanical seal:	Carbon, Ceramic, PTFE, stainless steel, HC-4 (2.4610)	Carbon, Ceramic, PTFE, stainless steel, HC-4 (2.4610)
Bearing:	Pure Carbon	Pure Carbon
Drive shaft:	stainless steel (1.4571)	stainless steel (1.4571)




Please remember that the flow rate is reduced as the **Viscosity** increases. The **Density** of the pumped liquid similarly affects the flow rate, though to a lesser extent.




Lutz Drum and Container Pumps

Pump tube RE-SS PURE (stainless steel) for complete drum drainage of aqueous and fatty foodstuffs

Product detail		Pump tube	RE-SS-MS	
	Type of impeller		L	L
	Category 1 / 2 (acc. to ATEX)		no	yes
	Immersion tube diameter:	up to mm	41	41
	Temperature of medium:	up to °C	100	100
	Material:	Pump tube Impeller	1.4571 PP	1.4571 ETFE
	Hose connection:	Tri-Clamp DN	32	32
	Length: 700 mm*** ▲	Order No. basic pump	0151-156	0151-156
	Length: 1000 mm*** ▲	Order No. basic pump	0151-157	0151-157
	Length: 1200 mm*** ▲	Order No. basic pump	0151-158	0151-158
	Version: PURE FPM ▲	Order No. additional price	–	0151-360
	Version: PURE EPDM ▲	Order No. additional price	0151-361	0151-362

▲Please choose Order-No. basic pump + Order-No. PURE additional price

Choice of motors				Operating data			
	MI 4		MI 4-E		Characteristic curve no.	700	
	-		with speed controller		Flow rate*	up to l/min. 78	
	Output: 500 W		500 W		Delivery head*	up to m wc 17	
	Voltage: 230 V		230 V		Viscosity**	up to mPas 700	
	Order No. 0030-000		0030-001		Density****	up to kg/dm³ 1,4	
					Weight (kg)	Motor + pump tube 6,0	
	MA II 3			Characteristic curve no.	701		
	Output: 460 W 460 W			Flow rate*	up to l/min. 77		
	Voltage: 230 V 230 V			Delivery head*	up to m wc 14		
	LVR.: no yes			Viscosity**	up to mPas 500		
	Order No. 0060-000 0060-008			Density****	up to kg/dm³ 1,6		
				Weight (kg)	Motor + pump tube 7,8		
	MA II 5			MA II 5	MA II 5 S	Characteristic curve no.	702
	Output: 575 W 575 W 575 W			Flow rate*	up to l/min. 77		
	Voltage: 230 V 230 V 230 V			Delivery head*	up to m wc 14		
	LVR.: no yes no			Viscosity**	up to mPas 900		
					acid-proof	Density****	up to kg/dm³ 1,8
	Order No. 0060-001 0060-009 0060-091			Weight (kg)	Motor + pump tube 8,6		
	MA II 7			Characteristic curve no.	703		
	Output: 795 W 795 W			Flow rate*	up to l/min. 70		
Voltage: 230 V 230 V			Delivery head*	up to m wc 18			
LVR.: no yes			Viscosity**	up to mPas 700			
Order No. 0060-002 0060-010			Density****	up to kg/dm³ 1,9			
			Weight (kg)	Motor + pump tube 9,8			
 	B4/GT			Characteristic curve no.	705		
	Output: 750 W 750 W			Flow rate*	up to l/min. 55		
	Voltage: 230/400 V 230/400 V			Delivery head*	up to m wc 8,5		
	Protection switch: no yes			Viscosity**	up to mPas 600		
	Order No. 0004-050 0004-052			Density****	up to kg/dm³ 2,2		
				Weight (kg)	Motor + pump tube 15,0		

Low-voltage release (LVR):
Prevents the pump from starting
up again without warning after a
power failure. It is recommended
when pumping hazardous
liquids.

Low-voltage release (LVR.): Prevents the pump from starting up again without warning after a power failure. It is recommended when pumping hazardous liquids.

* Determined with water at 20 °C
** Determined with oil

*** Special lengths 400–2000 mm on request

**** Determined with 3 m hose 3/4" and open nozzle 3/4". Higher densities possible for shorter operating periods.


Special voltages and frequencies on request.

Pump tube RE-SS PURE (stainless steel)

for complete drum drainage of aqueous and fatty foodstuffs

Materials (coming into contact with the pumped medium):

Version:	MS-FPM	MS-EPDM
Housing:	stainless steel (1.4571)	stainless steel (1.4571)
Impeller:	ETFE	ETFE, optional PP
Sealing pot:	ETFE/stainless steel (1.4571)	ETFE/stainless steel (1.4571)
Seals:	FPM, PTFE	EPDM, PTFE
Mechanical seal:	Carbon, Ceramic, PTFE, HC-4 (2.4610), stainless steel 1.4571)	Carbon, Ceramic, PTFE, HC-4 (2.4610), stainless steel 1.4571)
Bearing:	Pure Carbon	Pure Carbon
Drive shaft:	stainless steel (1.4571)	stainless steel (1.4571)




Complete drum drainage

Nearly completely drained.
Residual quantity < 0.10 litres.



Pump tube also available in PURE version with Tri-Clamp connection. All materials coming into contact with the pumped medium are physiologically safe. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.




Please remember that the flow rate is reduced as the **Viscosity** increases. The **Density** of the pumped liquid similarly affects the flow rate, though to a lesser extent.



Lutz Drum and Container Pumps



Pump tube RE-SS PURE (stainless steel) for complete drum drainage of alcoholic, highly flammable foodstuffs

Product detail	Pump tube	RE-SS MS
	Type of impeller	L
	Category 1 / 2 (acc. to ATEX)	yes
	Immersion tube diameter:	up to mm
	Temperature of medium:	up to °C
	Material:	Pump tube Impeller
	Hose connection:	Tri-Clamp DN
	Length: 700 mm*** ▲	Order No. basic pump
	Length: 1000 mm*** ▲	Order No. basic pump
	Length: 1200 mm*** ▲	Order No. basic pump
	Version: PURE FPM ▲	Order No. additional price
	Version: PURE EPDM ▲	Order No. additional price

▲Please choose Order-No. basic pump + Order-No. PURE additional price

Choice of motors	Operating data
 	ME II 3
	Output: 460 W 460 W
	Voltage: 230 V 230 V
	LVR.: yes no
	Order No. 0050-000 0050-016
	Characteristic curve no. 750
	Flow rate* up to l/min. 77
	Delivery head* up to m wc 14
	Viscosity** up to mPas 500
	Density**** up to kg/dm³ 1,6
	Weight (kg) Motor + pump tube 9,0
	ME II 5
	Output: 580 W 580 W
	Voltage: 230 V 230 V
	LVR.: yes no
	Order No. 0050-001 0050-017
	Characteristic curve no. 751
	Flow rate* up to l/min. 77
	Delivery head* up to m wc 14
	Viscosity** up to mPas 900
	Density**** up to kg/dm³ 1,8
	Weight (kg) Motor + pump tube 9,9
	ME II 7
	Output: 795 W 795 W
	Voltage: 230 V 230 V
	LVR.: yes no
	Order No. 0050-002 0050-018
	Characteristic curve no. 752
	Flow rate* up to l/min. 70
	Delivery head* up to m wc 18
	Viscosity** up to mPas 700
	Density**** up to kg/dm³ 1,9
	Weight (kg) Motor + pump tube 11,1
	ME II 8
	Output: 930 W 930 W
	Voltage: 230 V 230 V
	LVR.: yes no
	Order No. 0050-042 0050-041
	Characteristic curve no. 753
	Flow rate* up to l/min. 78
	Delivery head* up to m wc 22
	Viscosity** up to mPas 950
	Density**** up to kg/dm³ 1,9
	Weight (kg) Motor + pump tube 11,1

Low-voltage release (LVR):
Prevents the pump from starting up again without warning after a power failure. Compulsory for explosive areas, in case no special measures are taken (e.g. remote control).

* Determined with water at 20 °C
** Determined with oil

*** Special lengths
400–2000 mm on request

**** Determined with 3 m hose 3/4" and open nozzle 3/4".
Higher densities possible for shorter operating periods.


Special voltages and
frequencies on request.

Pump tube RE-SS PURE (stainless steel)

for complete drum drainage of alcoholic, highly flammable foodstuffs


Materials (coming into contact with the pumped medium):

Version:	MS-FPM	MS-EPDM
Housing:	stainless steel (1.4571)	stainless steel (1.4571)
Impeller:	ETFE	ETFE
Sealing pot:	ETFE/stainless steel (1.4571)	ETFE/stainless steel (1.4571)
Seals:	FPM, PTFE	EPDM, PTFE
Mechanical seal:	Carbon, Ceramic, PTFE, HC-4 (2.4610), stainless steel 1.4571)	Carbon, Ceramic, PTFE, HC-4 (2.4610), stainless steel 1.4571)
Bearing:	Pure Carbon	Pure Carbon
Drive shaft:	stainless steel (1.4571)	stainless steel (1.4571)



Tip

The right pump for "hot applications".





Pump tube also available in PURE version with Tri-Clamp connection. All materials coming into contact with the pumped medium are physiologically safe. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.


Please remember that the flow rate is reduced as the **Viscosity** increases. The **Density** of the pumped liquid similarly affects the flow rate, though to a lesser extent.


Lutz Drum and Container Pumps

Pump tube MP-SS PURE (stainless steel) for mixing and pumping of aqueous and fatty foodstuffs


Product detail		Pump tube	MP-SS-MS	
	Type of impeller		R	R
	Category 1 / 2 (acc. to ATEX)		no	yes
	Immersion tube diameter:	up to mm	41	41
	Temperature of medium:	up to °C	100	100
	Material:	Pump tube	1.4571	1.4571
		Impeller	SS	ETFE
	Hose connection:	Tri-Clamp DN	32	32
	Length: 1000 mm*** ▲	Order No. basic pump	0151-240	0151-240
	Length: 1225 mm*** ▲	Order No. basic pump	0151-255	0151-255
	Version: PURE FPM ▲	Order No. additional price	–	0151-355
Version: PURE EPDM ▲	Order No. additional price	0151-356	0151-357	
▲ Please choose Order-No. basic pump + Order-No. PURE additional price				

Choice of motors			Operating data	
	MI 4	MI 4-E	Characteristic curve no.	900
	-	with speed controller	Flow rate* up to l/min.	210
	Output: 500 W	500 W	Delivery head* up to m wc	10
	Voltage: 230 V	230 V	Viscosity** up to mPas	350
	Order No. 0030-000	0030-001	Density**** up to kg/dm³	1,1
		Weight (kg) Motor + pump tube	6,0	

	MA II 3			Characteristic curve no.	901
	Output: 460 W	460 W		Flow rate* up to l/min.	178
	Voltage: 230 V	230 V		Delivery head* up to m wc	9
	LVR.: no	yes		Viscosity** up to mPas	200
	Order No. 0060-000	0060-008		Density**** up to kg/dm³	1,2
			Weight (kg) Motor + pump tube	7,8	

	MA II 5	MA II 5	MA II 5 S	Characteristic curve no.	902
	Output: 575 W	575 W	575 W	Flow rate* up to l/min.	190
	Voltage: 230 V	230 V	230 V	Delivery head* up to m wc	10
	LVR.: no	yes	no	Viscosity** up to mPas	550
			acid-proof	Density**** up to kg/dm³	1,3
	Order No. 0060-001	0060-009	0060-091	Weight (kg) Motor + pump tube	8,6

Low-voltage release (LVR): Prevents the pump from starting up again without warning after a power failure. It is recommended when pumping hazardous liquids.	MA II 7			Characteristic curve no.	903
	Output: 795 W	795 W		Flow rate* up to l/min.	210
	Voltage: 230 V	230 V		Delivery head* up to m wc	13
	LVR.: no	yes		Viscosity** up to mPas	400
				Density**** up to kg/dm³	1,4
	Order No. 0060-002	0060-010		Weight (kg) Motor + pump tube	9,8

	B4/GT			Characteristic curve no.	905
	Output: 750 W	750 W		Flow rate* up to l/min.	140
	Voltage: 230/400 V	230/400 V		Delivery head* up to m wc	10,5
	Protection switch:	no	yes	Viscosity** up to mPas	400
				Density**** up to kg/dm³	2,0
	Order No. 0004-050	0004-052		Weight (kg) Motor + pump tube	15,0

* Determined with water at 20 °C
** Determined with oil

*** Special lengths
600–2500 mm on request

**** Determined with 3 m hose 3/4" and open nozzle 3/4".
Higher densities possible for shorter operating periods.


Special voltages and
frequencies on request.

Pump tube MP-SS PURE (stainless steel)

for mixing and pumping of aqueous and fatty foodstuffs

Materials (coming into contact with the pumped medium):

Version:	MS-FPM	MS-EPDM
Housing:	stainless steel (1.4571)	stainless steel (1.4571)
Impeller:	ETFE	ETFE optional SS
Seals:	FPM, PTFE	EPDM, PTFE
Mechanical seal:	Carbon, Ceramic, PTFE, HC-4 (2.4610), stainless steel 1.4571)	Carbon, Ceramic, PTFE, HC-4 (2.4610), stainless steel 1.4571)
Bearing:	Pure Carbon	Pure Carbon
Drive shaft:	stainless steel (1.4571)	stainless steel (1.4571)




Tip

Which pump for which liquid?
See resistance table

Please remember that the flow rate is reduced as the **Viscosity** increases. The **Density** of the pumped liquid similarly affects the flow rate, though to a lesser extent.




Pump tube also available in PURE version with Tri-Clamp connection. All materials coming into contact with the pumped medium are physiologically safe. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.





Lutz Drum and Container Pumps



Pump tube MP-SS PURE (stainless steel) for mixing and pumping of alcoholic, highly flammable foodstuffs

Product detail	Pump tube	MP-SS MS
	Type of impeller	R
	Category 1 / 2 (acc. to ATEX)	yes
	Immersion tube diameter:	up to mm
	Temperature of medium:	up to °C
	Material:	Pump tube Impeller
	Hose connection:	Tri-Clamp DN
	Length: 1000 mm*** ▲	Order No. basic pump
	Length: 1225 mm*** ▲	Order No. basic pump
	Version: PURE FPM ▲	Order No. additional price
	Version: PURE EPDM ▲	Order No. additional price

▲Please choose Order-No. basic pump + Order-No. PURE additional price

Choice of motors	Operating data
 	ME II 3
	Output: 460 W 460 W
	Voltage: 230 V 230 V
	LVR.: yes no
	Order No. 0050-000 0050-016
	Characteristic curve no. 950
	Flow rate* up to l/min. 178
	Delivery head* up to m wc 9
	Viscosity** up to mPas 200
	Density**** up to kg/dm³ 1,2
	Weight (kg) Motor + pump tube 9,0
	ME II 5
	Output: 580 W 580 W
	Voltage: 230 V 230 V
	LVR.: yes no
	Order No. 0050-001 0050-017
	Characteristic curve no. 951
	Flow rate* up to l/min. 190
	Delivery head* up to m wc 10
	Viscosity** up to mPas 550
	Density**** up to kg/dm³ 1,3
	Weight (kg) Motor + pump tube 9,9
	ME II 7
	Output: 795 W 795 W
	Voltage: 230 V 230 V
	LVR.: yes no
	Order No. 0050-002 0050-018
	Characteristic curve no. 952
	Flow rate* up to l/min. 210
	Delivery head* up to m wc 13
	Viscosity** up to mPas 400
	Density**** up to kg/dm³ 1,4
	Weight (kg) Motor + pump tube 11,1
	ME II 8
	Output: 930 W 930 W
	Voltage: 230 V 230 V
	LVR.: yes no
	Order No. 0050-042 0050-041
	Characteristic curve no. 953
	Flow rate* up to l/min. 216
	Delivery head* up to m wc 14,5
	Viscosity** up to mPas 650
	Density**** up to kg/dm³ 1,4
	Weight (kg) Motor + pump tube 11,1

Low-voltage release (LVR):
Prevents the pump from starting up again without warning after a power failure. Compulsory for explosive areas, in case no special measures are taken (e.g. remote control).

* Determined with water at 20 °C
** Determined with oil

*** Special lengths
600–2500 mm on request

**** Determined with 3 m hose 3/4" and open nozzle 3/4".
Higher densities possible for shorter operating periods.



Special voltages and frequencies on request.

Pump tube MP-SS PURE (stainless steel)

for mixing and pumping of alcoholic, highly flammable foodstuffs

Materials (coming into contact with the pumped medium):

Version:	MS-FPM	MS-EPDM
Housing:	stainless steel (1.4571)	stainless steel (1.4571)
Impeller:	ETFE	ETFE
Seals:	FPM, PTFE	EPDM, PTFE
Mechanical seal:	Carbon, Ceramic, PTFE, HC-4 (2.4610), stainless steel 1.4571)	Carbon, Ceramic, PTFE, HC-4 (2.4610), stainless steel 1.4571)
Bearing:	Pure Carbon	Pure Carbon
Drive shaft:	stainless steel (1.4571)	stainless steel (1.4571)



Please remember that the flow rate is reduced as the **Viscosity** increases. The **Density** of the pumped liquid similarly affects the flow rate, though to a lesser extent.

Lutz Eccentric Screw Pumps in PURE Version



Lutz Eccentric Screw Pumps HD-E SS in PURE Version

The Lutz HD-E combines the advantages of a handy drum pump and the gentle operation of a robust eccentric screw pump. Ideal for pumping viscous raw materials and food products.

- + Ideal for slightly to moderately viscous liquids
- + Gentle product pumping
- + Quiet operation
- + Easy handling
- + Simple cleaning without tools
- + Not filled with lubricants, preventing product contamination



Properties:

- Displacement pump using the eccentric screw principle
Materials in contact with liquids in food quality
- Low pulsation, even pumping flow
- Practically no abrasive effect on the medium
- Compact dimensions
- Easily detachable outer pipe
- High-performance single-phase 230 V/ 50 Hz motor

Lutz Eccentric Screw Pumps B70V PURE in PURE Version

Lutz B70V PURE series eccentric screw pumps are well-suited for liquids which are highly viscous or susceptible to abrasion, as well as liquids with and without fibre or solid content. Quiet-running, low-wear three-phase drives, or reduction gear and universal drive for mobile use.

- + For liquids susceptible to abrasion or highly viscous liquids
- + Gentle product pumping
- + Variable flow rate (in conjunction with speed controller / frequency converter)
- + Easy handling
- + Quick-action motor coupling enables the motor and pump tube to be connected and separated quickly
- + Quick to dismantle, easy to clean
- + Not filled with lubricants, preventing product contamination



Properties:

- Displacement pump using the eccentric screw principle
- Materials in contact with liquids in food quality
- Low pulsation, even pumping flow
- Practically no abrasive effect on the medium
- Easily detachable outer pipe
- For mobile and stationary use
- Optionally available with integrated frequency converter



Lutz Eccentric Screw Pumps



Lutz HD-E PURE for medium viscous foodstuffs



The intelligent solution for the pumping of medium viscosity liquids

High efficiency, handy, low weight and easily disassembled for easy cleaning make the Lutz HD-E a practical drum pump system especially for medium viscosity liquids. It is suitable for pumping acids and basic liquids, oils, used oil, waste disposal liquids, colours, foodstuffs, cosmetics and creams.

- ✓ Light and compact
- ✓ Simple and easily dismantled
- ✓ Easy to clean
- ✓ Suitable for continuous operation
- ✓ Practical Lutz hand wheel for motor separation and to carry
- ✓ Smooth flow
- ✓ For thin and thick liquids
- ✓ Constant volumetric flow

Product detail		Pump tube		HD-E PURE	
	Category 1 / 2 (acc. to ATEX)			no	
	Immersion tube diameter:	max. mm		41	
	Temperature of medium:	max. °C		100	
	Material:	Pump tube		Stainless steel (1.4571)	
		Stator		PTFE	
	Hose connection:	Tri-Clamp DN		32	
	Length: 1000 mm ▲*	Order-No. basic pump		0155-010	
	Version PURE FPM ▲	Order-No. additional price		0155-016	
	Version PURE EPDM ▲	Order-No. additional price		0155-017	
	▲Please choose Order-No. basic pump + Order-No. PURE additional price				
Choice of motors		Operating data			
	Single phase motor				
	Output:	0,55 kW	Delivery rate	up to l/min.	20
	Voltage:	230 V	Delivery head	up to bar	4
	Speed:	1500 1/min.	Viscosity	mPas	500-4000
	Protection class:	IP 54	Weight (kg)	Motor + pump tube	11,5
	Order-No.	0155-032			


* Special lengths 600–1500 mm on request

Materials (coming into contact with the pumped medium)

Version:	HD-E PURE FPM	HD-E PURE EPDM
Pump tube:	Stainless steel (1.4571)	Stainless steel (1.4571)
Stator:	PTFE	PTFE
Mechanical seal:	Stainless steel/Carbon/FPM	Stainless steel/Carbon/EPDM
Secondary seal:	FPM	EPDM
Drive shaft:	Stainless steel (1.4571)	Stainless steel (1.4571)



Pump tube in PURE version also available with Tri-Clamp-connection. All materials coming into contact with the pumped medium are physiologically safe. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.



1 Bearing head with mechanical seal

- Compact unit for bearing and bearing shaft
- Wide range of mechanical seals

2 Easy detachable pump tube


- Easy cleaning
- No tools for disassembling of pump

3 Free running drive shaft

- Easy to clean

4 Delivery element eccentric

- Smooth pumping of liquids
- High pressure
- Constant volumetric flow



B70V-SR 12.1, 25.1 and 50.1 PURE

for viscosities from 1 - 30,000 mPas

Materials (coming into contact with the pumped medium):

Version:	B70V-SR PURE PTFE/FPM	B70V-SR PURE PTFE/EPDM
Housing:	Stainless steel (1.4571/1.4404)	Stainless steel (1.4571/1.4404)
Rotor:	Stainless steel (1.4571)	Stainless steel (1.4571)
Seals:	FPM	EPDM
Mechanical seal:		
Torsion shaft	WC/SiC/FPM	WC/SiC/EPDM
Universal joint shaft	WC/WC/FPM	WC/WC/EPDM
Drive shaft:	Stainless steel (1.4571)	Stainless steel (1.4571)
Stator material:	PTFE	PTFE





Pump tube with PTFE stator, also available in PURE version with Tri-Clamp-connection. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.

Important Information!

When pumping in „Zone 0“ areas or pumping flammable liquids only pumps with mechanical seal, universal joint shaft and PTFE stator are approved.




Viscosity range from aqueous to fluidity range.

Medium table with liquid examples see chemical resistance table.



Lutz Eccentric Screw Pumps

B70V 12.1 and 25.1 PURE for viscous foodstuffs

Product detail		B70V PURE			
		Pump tubes	12.1	12.1	25.1
		Size	12.1	12.1	25.1
		Category 1 / 2 (acc. to ATEX)	no	yes	no
		Seal Mechanical seal (MS)	MS	MS	MS
		Drive shaft Torsion shaft (TS)	TS	UJ	TS
		Universal joint shaft (UJ)			UJ
		Delivery rate* up to l/min.	12	12	25
		Delivery head* up to bar	6	6	6
		Temp. of medium** max. °C	140	140	140
		Material pump tube	1.4571/1.4404	1.4571/1.4404	1.4571/1.4404
		Material stator	PTFE	PTFE	PTFE
		Immersion tube diameter mm	54	54	54
		Pressure joint Tri-Clamp DN	50	50	50
		Weight kg	7	7	7
		Length*** mm	1000	1000	1000
		Order-No. basic pump ▲	0172-004	0173-014	0172-124
		Order-No. additional price PURE FPM ▲	0172-128	0173-138	0172-128
		Order-No. additional price PURE EPDM ▲	0172-129	0173-139	0172-129
<p>▲ Please choose Order-No. basic pump + Order-No. PURE additional price</p> <p>* Determined with water at 20 °C, three-phase motor (900 rpm) and elastomer stator</p> <p>** with PTFE Stator (the medium temperature of explosion proof eccentric screw pumps B70 may not exceed 100°C)</p> <p>*** Special length 500 - 2000 mm on request (version with joint shaft only)</p> <p>● Explosion proof eccentric screw pump approved category 1 / 2 (acc. to ATEX) for pumping flammable liquids of the explosion group IIA and temperature class T4</p>					
					
Choice of motors					
		Motors with cable terminal box	For B70V - 12.1		For B70V - 25.1
		Type	0,37 kW, 700 1/min.	0,55 kW, 900 1/min.	0,55 kW, 700 1/min.
		Protection class/Weight	IP 55 16 kg	IP 55 12 kg	IP 55 16 kg
		Order-No.	0172+803	0172+806	0172+809
		Motors with protection switch	For B70V - 12.1		For B70V - 25.1
		Type	0,37 kW, 700 1/min.	0,55 kW, 900 1/min.	0,55 kW, 700 1/min.
		Protection class/Weight	IP 54 16 kg	IP 54 12 kg	IP 54 16 kg
		Order-No.	0172+802	0172+805	0172+808
		Motors, explosion proof	For B70V - 12.1		For B70V - 25.1
		Type	0,37 kW, 700 1/min.	0,55 kW, 900 1/min.	0,55 kW, 700 1/min.
		Type of protection	II 2 G Ex e II T3	II 2 G Ex e II T3	II 2 G Ex e II T3
		Protection class/Weight	IP 55 19 kg	IP 55 17 kg	IP 55 22 kg
		Order-No.	0172-801	0172-804	0172-807
		Motors with frequency converter	For B70V - 12.1		For B70V - 25.1
		Type	0,55 kW, 0-900 1/min.	0,55 kW, 0-900 1/min.	0,75 kW, 0-900 1/min.
		Protection class/Weight	IP 55 16 kg	IP 55 16 kg	IP 55 22 kg
		Order-No.	0172-769	0172-769	0172-768

Three-phase motor
230/400 V, 50 Hz,
Energy efficiency class
IE 3 in accordance
with EU regulations
640/2009 and 04/2014
Special voltages,
frequencies, protection
classes as well as higher
explosion proof protec-
tion classes on request.

B70V 12.1 and 25.1 PURE

for viscosities from 1 - 100,000 mPas

Materials (coming into contact with the pumped medium):

Version:	B70V PURE PTFE/FPM	B70V PURE PTFE/EPDM
Housing:	Stainless steel (1.4571/1.4404)	Stainless steel (1.4571/1.4404)
Rotor:	Stainless steel (1.4571)	Stainless steel (1.4571)
Seals:	FPM	EPDM
Mechanical seal:		
Torsion shaft	WC/SiC/FPM	WC/SiC/EPDM
Universal joint shaft	WC/WC/FPM	WC/WC/EPDM
Drive shaft:	Stainless steel (1.4571)	Stainless steel (1.4571)
Stator material:	PTFE	PTFE





Pump tube with PTFE stator, also available in PURE version with Tri-Clamp-connection. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.

Important Information!

When pumping in „Zone 0“ areas or pumping flammable liquids only pumps with mechanical seal, universal joint shaft and PTFE stator are approved.




Viscosity range from aqueous to fluidity range.

Medium table with liquid examples see chemical resistance table.



Lutz Eccentric Screw Pumps

B70V 25.2 PURE for viscous foodstuffs

Product detail		Pump tubes		B70V PURE	
	Size		25.2		25.2
	Category 1 / 2 (acc. to ATEX)		no		yes
	Seal	Packing gland (St) Mechanical seal (MS)	MS		MS
	Drive shaft	Torsion shaft (TS) Universal joint shaft (UJ)	TS		UJ
	Delivery rate*	up to l/min.	25		25
	Delivery head*	up to bar	10		10
	Temp. of medium**	max. °C	140		140
	Material pump tube		1.4571/1.4404		1.4571/1.4404
	Material stator		PTFE		PTFE
	Immersion tube diameter	mm	54		54
	Pressure joint	Tri-Clamp DN	50		50
	Weight	kg	7		7
	Length***	mm	1100		1100
	Order-No. basic pump ▲		0172-254		0173-264
	Order-No. additional price PURE FPM ▲		0172-128		0173-138
	Order-No. additional price PURE EPDM ▲		0172-129		0173-139
<p>▲Please choose Order-No. basic pump + Order-No. PURE additional price</p> <p>* Determined with water at 20 °C, three-phase motor (900 rpm) and elastomer stator</p> <p>** with PTFE Stator (the medium temperature of explosion proof eccentric screw pumps B70 may not exceed 100°C)</p> <p>*** Special length 500 - 2000 mm on request (version with joint shaft only)</p> <p>● Explosion proof eccentric screw pump approved category 1 / 2 (acc. to ATEX) for pumping flammable liquids of the explosion group IIA and temperature class T4</p>					
					
Choice of motors					
	Motors with cable terminal box		For B70V - 25.2		
	Type		0,75 kW, 700 1/min.		1,1 kW, 900 1/min.
	Protection class/Weight		IP 55 18 kg		IP 55 34 kg
	Order-No.		0172+815		0172-903
	Motors with protection switch		For B70V - 25.2		
	Type		0,75 kW, 700 1/min.		1,1 kW, 900 1/min.
	Protection class/Weight		IP 54 18 kg		IP 54 34 kg
	Order-No.		0172+814		0172-902
	Motors, explosion proof		For B70V - 25.2		
	Type		0,65 kW, 700 1/min.		1,0 kW, 900 1/min.
	Type of protection		II 2 G Ex e II T3		II 2 G Ex e II T3
	Protection class/Weight		IP 55 27 kg		IP 55 23 kg
	Order-No.		0172-813		0172-816
	Motors with frequency converter		For B70V - 25.2		
	Type		1,1 kW, 0-900 1/min.		
	Protection class/Weight		IP 55 25 kg		
	Order-No.		0172-767		

Three-phase motor
230/400 V, 50 Hz,
Energy efficiency class
IE 3 in accordance
with EU regulations
640/2009 and 04/2014
Special voltages,
frequencies, protection
classes as well as higher
explosion proof protec-
tion classes on request.

B70V 25.2 PURE

for viscosities from 1 - 100,000 mPas

Materials (coming into contact with the pumped medium):

Version:	B70V PURE PTFE/FPM	B70V PURE PTFE/EPDM
Housing:	Stainless steel (1.4571/1.4404)	Stainless steel (1.4571/1.4404)
Rotor:	Stainless steel (1.4571)	Stainless steel (1.4571)
Seals:	FPM	FPM or EPDM
Mechanical seal:		
Torsion shaft	WC/SiC/FPM	WC/SiC/EPDM
Universal joint shaft	WC/WC/FPM	WC/WC/EPDM
Drive shaft:	Stainless steel (1.4571)	Stainless steel (1.4571)
Stator material:	PTFE	PTFE





Pump tube with PTFE stator, also available in PURE version with Tri-Clamp-connection. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.

Important Information!

When pumping in „Zone 0“ areas or pumping flammable liquids only pumps with mechanical seal, universal joint shaft and PTFE stator are approved.

Viscosity range from aqueous to fluidity range.

Medium table with liquid examples see chemical resistance table.



B70V 50.1 and 75.1 PURE for viscous foodstuffs

Product detail

Pump tubes		B70V PURE		
Size		50.1	50.1	75.1
Category 1 / 2 (acc. to ATEX)		no	yes	no
Seal	Packing gland (St) Mechanical seal (MS)	MS	MS	MS
Drive shaft	Torsion shaft (TS) Universal joint shaft (UJ)	TS	UJ	UJ
Delivery rate*	up to l/min.	50	50	75
Delivery head*	up to bar	6	6	6
Temp. of medium**	max. °C	140	140	140
Material pump tube		1.4571/1.4404	1.4571/1.4404	1.4571/1.4404
Material stator		PTFE	PTFE	PTFE
Immersion tube diameter	mm	54	54	54
Pressure joint	Tri-Clamp DN	50	50	50
Weight	kg	7	7	7
Length***	mm	1100	1100	1100
Order-No. basic pump ▲		0172-504	0173-514	0173-564
Order-No. additional price PURE FPM ▲		0172-128	0173-138	0173-140
Order-No. additional price PURE EPDM ▲		0172-129	0173-139	0173-141

▲ Please choose Order-No. basic pump + Order-No. PURE additional price

* Determined with water at 20 °C, three-phase motor (900 rpm) and elastomer stator

** with PTFE Stator (the medium temperature of explosion proof eccentric screw pumps B70 may not exceed 100°C)

*** Special length 500 - 2000 mm on request (version with joint shaft only)

● Explosion proof eccentric screw pump approved category 1 / 2 (acc. to ATEX)
for pumping flammable liquids of the explosion group IIA and temperature class T4

Choice of motors

Three-phase motor
230/400 V, 50 Hz,
Energy efficiency class
IE 3 in accordance
with EU regulations
640/2009 and 04/2014
Special voltages,
frequencies, protection
classes as well as higher
explosion proof protec-
tion classes on request.

Motors with cable terminal box		For B70V - 50.1		
Type		1,1 kW, 700 1/min.	1,1 kW, 900 1/min.	
Protection class/Weight		IP 55 22 kg	IP 55 34 kg	
Order-No.		0172+826	0172-903	
Motors with cable terminal box		For B70V - 75.1		
Type		1,1 kW, 700 1/min.	1,5 kW, 700 1/min.	1,5 kW, 900 1/min.
Protection class/Weight		IP 55 22 kg	IP 55 34 kg	IP 55 34 kg
Order-No.		0172+826	0172-761	0172-905
Motors with protection switch		For B70V - 50.1		
Type		1,1 kW, 700 1/min.	1,1 kW, 900 1/min.	
Protection class/Weight		IP 54 22 kg	IP 54 34 kg	
Order-No.		0172+825	0172-902	
Motors with protection switch		For B70V - 75.1		
Type		1,1 kW, 700 1/min.	1,5 kW, 700 1/min.	1,5 kW, 900 1/min.
Protection class/Weight		IP 54 22 kg	IP 54 34 kg	IP 54 34 kg
Order-No.		0172+825	0172-760	0172-904
Motors, explosion proof		For B70V - 50.1		
Type		0,65 kW, 700 1/min.	1,0 kW, 900 1/min.	
Type of protection		II 2 G Ex e II T3	II 2 G Ex e II T3	
Protection class/Weight		IP 55 27 kg	IP 55 23 kg	
Order-No.		0172-813	0172-816	
Motors with frequency converter		For B70V - 50.1		
Version		1,1 kW, 0-900 1/min.	1,5 kW, 0-900 1/min.	
Protection class/Weight		IP 55 25 kg	IP 55 37 kg	
Order-No.		0172-767	0172-766	

B70V 50.1 and 75.1 PURE

for viscosities from 1 - 100,000 mPas

Materials (coming into contact with the pumped medium):

Version:	B70V PURE PTFE/FPM	B70V PURE PTFE/EPDM
Housing:	Stainless steel (1.4571/1.4404)	Stainless steel (1.4571/1.4404)
Rotor:	Stainless steel (1.4571)	Stainless steel (1.4571)
Seals:	FPM	EPDM
Mechanical seal:		
Torsion shaft	WC/SiC/FPM	WC/SiC/EPDM
Universal joint shaft	WC/WC/FPM	WC/WC/EPDM
Drive shaft:	Stainless steel (1.4571)	Stainless steel (1.4571)
Stator material:	PTFE	PTFE





Pump tube with PTFE stator, also available in PURE version with Tri-Clamp-connection. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.

Important Information!

When pumping in „Zone 0“ areas or pumping flammable liquids only pumps with mechanical seal, universal joint shaft and PTFE stator are approved.

Viscosity range from aqueous to fluidity range.


Medium table with liquid examples see chemical resistance table.



Lutz Eccentric Screw Pumps

B70V 120.1 PURE for viscous and pasty foodstuffs

Product detail



Pump tubes		B70V PURE
Size		120.1
Category 1 / 2 (acc. to ATEX)		no
Seal	Mechanical seal (MS)	MS
Drive shaft	Universal joint shaft (UJ)	UJ
Delivery rate*	up to l/min.	120
Delivery head*	up to bar	6
Temp. of medium	max. °C	140
Material pump tube		1.4571
Material stator		PTFE
Pumpendurchmesser**	max. mm	131
Pressure joint	Tri Clamp DN	50
Weight	kg	21
Length***	mm	1100
Order-No. basic pump ▲		0175-204

Order-No. additional price PURE FPM ▲	0175-208
Order-No. additional price PURE EPDM ▲	0175-209


▲ Please choose Order-No. basic pump + Order-No. PURE additional price

* Determined with water at 20 °C, three-phase motor (600 rpm and 700 rpm) and elastomer stator

** required bunghole Ø 133 mm

*** Special length 500 - 2000 mm on request

Choice of motors



Motors with cable terminal box	For B70V - 120.1	
Type	2,2 kW, 600 1/min.	3,0 kW, 600 1/min.
Protection class/Weight	IP 55 42 kg	IP 55 47 kg
Order-No.	0175-802	0175-803

Motors with frequency converter	For B70V - 120.1
Version	3,0 kW, 0-600 1/min.
Protection class/Weight	IP 55 45 kg
Order-No.	0175+802

Three-phase motors 230/400 V, 50 Hz,
Energy efficiency class IE 3 in accordance with EU regulations 640/2009 and 04/2014
Special voltages, frequencies, protection class on request.

B70V 120.1 PURE

for viscosities from 1 - 120.000 mPas


Materials (coming into contact with the pumped medium):

Version:	B70V PURE PTFE/FPM	B70V PURE PTFE/EPDM
Housing:	Stainless steel (1.4571)	Stainless steel (1.4571)
Rotor:	Stainless steel (1.4571)	Stainless steel (1.4571)
Seals:	FPM	EPDM
Mechanical seal:*	WC/WC, FPM	WC/WC, EPDM
Drive shaft:	Stainless steel (1.4571)	Stainless steel (1.4571)
Stator material:	PTFE	PTFE

* Mechanical seal pairing on request.



Pump tube with PTFE stator, also available in PURE version with Tri-Clamp-connection. The pump tubes are mainly used in the food-, cosmetics- and pharmaceutical industry.



Range 1:

Thin-bodied and lubricating fluids such as wine, milk, oils etc.
 $\eta < 7000$ mPas

Range 2:



Abrasive and viscous fluids such as pulps, adhesives, paints, inks, etc.
 $\eta < 20,000$ mPas

Range 3:

Very abrasive and highly viscous fluids such as honey, greases, syrups, etc.
 $\eta > 20,000$ mPas

Viscosity range:

Up to limit of flowability





In order to ensure a reliable filling process, the hoses, nozzles and curved spouts meet the requirements of the food and beverage industry.



Other accessories for food and beverages

In order to ensure a reliable filling process, the hoses, nozzles and curved spouts meet the requirements of the food and beverage industry.



Certified Quality

All materials used have been tested and conform to the required standards. Our high quality standards are certified by a declaration of conformity.



Lutz Flow Meter

TS VA10 SS in PURE Version

The VA10 SS PURE flow measurement device with touch screen display and backlighting is very impressive thanks to its simple, practical display and user-friendly operation, multi-language interface and compact construction. The user guide with instructions in plain text, system reporting and assistance texts as well as safety and monitoring functions virtually eliminate the possibility of errors. It can also be operated manually or by external control.

- + Precise volume detection of liquid food products and raw materials
- + Practical display and user-friendly operation
- + User-error protection
- + High measurement precision thanks to overrun correction
- + Simple calibration
- + Easy installation and starting up
- + External control / data evaluation via standard interfaces



Properties:

- Operates via nutating disc
- Materials in contact with liquids in food quality
- Touch screen display
- Multi-language menu guide
- Instructions in plain text
- Integrated assistance function
- Safety and monitoring functions
- With and without volume preselection
- "Plug & Play" module concept
- Explosion-proof versions approved in accordance with the ATEX Directive 2014/34/EU Category 1/2



Volume preset

A relay module which can be integrated into the metering system automatically shuts off the pump motor and/or solenoid valve once the volume preset has been reached.

Flow measurement without volume preselection - TS

for aqueous, fatty and highly flammable foodstuffs



Flow meters type VA10 in PURE-version are optionally available for the food-, cosmetics and pharmaceutical industry.



Technical data		Typ VA10 PURE	Typ VA10 Ex PURE
Range of use		aqueous and fatty foodstuffs	highly flammable foodstuffs
Flow volume	l/min.	min. 10 – max. 100	min. 10 – max. 100
Temperature	°C	80	60
Viscosity	mPas	5.000	5.000
Operating pressure	bar	10	10
Accuracy		± 1%	± 1%
Inlet and Outlet port		Tri-Clamp DN 32	Tri-Clamp DN 32
LCD display		Touch-Screen 63x63 mm, 128x128 pixels, sub-total volume can be reset	
Menu language		DE, GB, ES, FR, IT, NL, PT, RU	
Materials:			
Housing		Stainless steel (1.4581/1.4571)*	Stainless steel (1.4581/1.4571)*
Measuring chamber		Stainless steel (1.4581/1.4571) PTFE/PVDF	Stainless steel (1.4581/1.4571) PTFE/PVDF/PE
Seals		FEP	FEP
Magnet		PVDF encapsulated	PVDF encapsulated
Type of protection:			
Operating unit		–	II 2 G Ex ib IIB T4**
Basic flow meter		–	II 2 G T4
Protection class		IP 55	IP 55
Weight	kg	3,7	3,7
Order-No. basic flow meter [▲]		0231-049	0231-040 ●

* Special materials on request General information to the chemical resistance of the different flow meters you will find in our chemical resistance list.

** Protection class II 2 G Ex ib IIC T4 on request.

Order-No. PURE additional price	0230-330	0230-331
---------------------------------	----------	----------

[▲]Please choose Order-No. basic flow meter + Order-No. PURE additional price

Recommended Accessories: Power supply unit NG10***		
Voltage	V	220-240
Frequency	Hz	50-60
Order-No.		0230-230

*** Limited battery operation without power supply unit possible.

● Suitable for transferring combustible and easy flammable liquids (e.g. ethanol, petrol) or in explosive hazard area.

Flow measurement with volume preselection - TS

for aqueous, fatty and highly flammable foodstuffs



Flow meters type VA10 in PURE-version are optionally available for the food-, cosmetics and pharmaceutical industry.



Technical data		Typ VA10/RM10 PURE	Typ VA10/Ex-RM10dK PURE
Range of use		aqueous and fatty foodstuffs	highly flammable foodstuffs
Flow volume	l/min.	min. 10 – max. 100	min. 10 – max. 100
Temperature	°C	80	40
Viscosity	mPas	5.000	5.000
Operating pressure	bar	10	10
Accuracy		± 1%	± 1%
Inlet and Outlet port		Tri-Clamp DN 32	Tri-Clamp DN 32
LCD display		Touch-Screen 63x63 mm, 128x128 pixels, sub-total volume can be reset	
Menu language		DE, GB, ES, FR, IT, NL, PT, RU	
Materials:			
Housing		Stainless steel (1.4581/1.4571)*	Stainless steel (1.4581/1.4571)*
Measuring chamber		Stainless steel (1.4581/1.4571) PTFE/PVDF	Stainless steel (1.4581/1.4571) PTFE/PVDF/PE
Seals		FEP	FEP
Magnet		PVDF encapsulated	PVDF encapsulated
Type of protection:			
Operating unit		–	II 2 G Ex ib IIB T4** 
Basic flow meter		–	II 2 G T4
Protection class		IP 55	IP 55
Weight	kg	4,1	6,7
Relay module		RM10 230 V	Ex-RM10dK 230 V
Voltage	V	220-240	220-240
Frequency	Hz	50-60	50-60
Switching outputs		2 NO (potentially bound)	2 NO (potentially bound)
Output 1 (pump)		8 A, $\cos\varphi > 0,7$	8 A, $\cos\varphi > 0,7$
Output 2 (valve)		0,5 A	0,5 A
Type of protection		–	II 2 G Ex de [ib Gb] IIC T6 Gb
Order-No. basic flow meter[▲]		0231-041	0231-040 ● + 0230-251 ●

* Special materials on request General information to the chemical resistance of the different flow meters you will find in our chemical resistance list.


** Protection class II 2 G Ex ib IIC T4 on request.

Order-No. PURE additional price[▲]	0230-330	0230-331
--	-----------------	-----------------

[▲]Please choose Order-No. basic flow meter + Order-No. PURE additional price

Accessories

Accessories at a glance



1 ● Hose

2 Hose clamp

3 Hose connection

4 Hose connector

5 Tri-Clamp reducing piece

6 Tri-Clamp locking clamp

7 ● Discharge spout

8 ● Discharge spout

11 Drum adapter

12 Clamping device

13 Installation flange

14 Wall bracket

16 ● Balancer

17 Equipotential bonding cable

18 ● Ex-plug

19 ● Ex-socket

20 ● Lifting device

21 Impulse transmitter

22 ● Protection device for drum inliner


23 ● Operating unit

● Suitable for transferring combustible and easy flammable liquids (e.g. ethanol, petrol) or in explosive hazard area.

Specification	Order-No.	Product detail
<p>1 PVC spiral hose</p> <p>Hose for food liquids made of PVC with woven layer and embedded galvanized steel spiral, smooth interior and exterior, complies with EU Regulation 1935/2004 EG.</p> <p>Operating pressure: max. 14 bar Temp. of medium: -5 °C up to +65 °C Nominal diameter: Weight: DN 25 (1") 0,67 kg/m DN 32 (1 1/4") 0,80 kg/m DN 38 (1 1/2") 1,15 kg/m DN 50 (2") 1,60 kg/m</p>	<p>0374-467 0374-468 0374-469 0374-470</p>	
<p>1 Food chemical hose</p> <p>Colour coding: "blue/white/blue". Suitable for 95% of all customary industrial chemicals such as almost all acids and alkalis, mineral oil products and solvents of all kinds. Ideal for food and luxury foodstuffs, pharmaceuticals, cosmetics and hygiene products, complies with EU Regulation EC 1935/2004 and EC 10/2011, FDA and ATEX requirements. Foodstuff conformity of inner layer. Internal finish: UPE light with spiraled OHM conductive stripes UPE black, smooth, non-bleeding, abrasion-resistant. Intermediate layer: EPDM conductive External finish: EPDM light grey, conductive, non-bleeding, ozone- and UV resistant, hardly flammable, Type Ω/T smaller than 10⁶ Ohm (acc. to DIN EN 12115:2011).</p> <p>Operating pressure: up to 16 bar Temperature of medium: -30 up to +100 °C can be sterilized at 130°C for 30 minutes (open system)</p> <p>Nominal diameter: Weight: DN 25 (1") 0,8 kg/m DN 32 (1 1/4") 0,9 kg/m DN 38 (1 1/2") 1,2 kg/m DN 50 (2") 1,9 kg/m</p>	<p>0374-476 ● 0374-477 ● 0374-478 ● 0374-479 ●</p>	
<p>2 Stepless 1-ear hose clamp</p> <p>1-ear hose clamp of stainless steel for the safe fixing of different hoses onto the hose connection.</p> <p>for Tri-Clamp 0204-872 / PVC spiral hose DN 25, fabric reinforced for Tri-Clamp 0204-872 / Food chemical hose DN 25</p> <p>for Tri-Clamp 0204-874 / PVC spiral hose DN 32, fabric reinforced for Tri-Clamp 0204-874 / Food chemical hose DN 32</p> <p>for Tri-Clamp 0204-876 / PVC spiral hose DN 38, fabric reinforced for Tri-Clamp 0204-876 / Food chemical hose DN 38</p> <p>for Tri-Clamp 0204-872 / PVC spiral hose DN 50, fabric reinforced for Tri-Clamp 0204-872 / Food chemical hose DN 50</p>	<p>0300-446 0300-442 0300-453 0300-460 0300-465 0300-465 0300-473 0300-477</p>	

Accessories

For B70V SanitaryPlus and B70 PURE

Product detail	Specification	Order-No.																																																																														
 <p>Caution: The assembler is responsible for the professional bonding of the hose according to the current Pressure Equipment Directive.</p>	<p>3 Hose connection with Tri-Clamp</p> <p>For connection of the hose onto the eccentric screw pump B70, discharge spout or Tri-clamp armatures (consisting of hose connector, locking clamp and seal) Material: Stainless steel (1.4404)</p> <table><tr><td>Connection:</td><td>for hose with nominal diameter:</td><td>Seal:</td><td></td></tr><tr><td>Tri-Clamp DN 32**</td><td>DN 19 (3/4")</td><td>EPDM</td><td>0204-870</td></tr><tr><td>Tri-Clamp DN 32**</td><td>DN 19 (3/4")</td><td>FPM</td><td>0204-871</td></tr><tr><td>Tri-Clamp DN 32**</td><td>DN 25 (1")</td><td>EPDM</td><td>0204-872</td></tr><tr><td>Tri-Clamp DN 32**</td><td>DN 25 (1")</td><td>FPM</td><td>0204-873</td></tr><tr><td>Tri-Clamp DN 32**</td><td>DN 32 (1 1/4")</td><td>EPDM</td><td>0204-874</td></tr><tr><td>Tri-Clamp DN 32**</td><td>DN 32 (1 1/4")</td><td>FPM</td><td>0204-875</td></tr><tr><td>Tri-Clamp DN 32**</td><td>DN 38 (1 1/2")</td><td>EPDM</td><td>0204-876</td></tr><tr><td>Tri-Clamp DN 32**</td><td>DN 38 (1 1/2")</td><td>FPM</td><td>0204-877</td></tr><tr><td>Tri-Clamp DN 50</td><td>DN 38 (1 1/2")</td><td>EPDM</td><td>0172-746</td></tr><tr><td>Tri-Clamp DN 50</td><td>DN 38 (1 1/2")</td><td>FPM</td><td>0204-878</td></tr><tr><td>Tri-Clamp DN 50</td><td>DN 50 (2")</td><td>EPDM</td><td>0204-879</td></tr><tr><td>Tri-Clamp DN 50</td><td>DN 50 (2")</td><td>FPM</td><td>0204-880</td></tr></table> <p>For individual needs, e.g. for connection to on-site Tri-clamp armatures:</p> <p>Tri-clamp hose connector (1.4404):</p> <table><tr><td>DN 32 for hose DN 19</td><td>0370-093</td></tr><tr><td>DN 32 for hose DN 25</td><td>0370-094</td></tr><tr><td>DN 32 for hose DN 32</td><td>0370-095</td></tr><tr><td>DN 32 for hose DN 38</td><td>0370-096</td></tr><tr><td>DN 50 for hose DN 50</td><td>0370-097</td></tr></table> <p>Tri-clamp locking clamp (1.4408):</p> <table><tr><td>DN 25/32/40</td><td>0370-088</td></tr><tr><td>DN 50</td><td>0370-084</td></tr></table> <p>Tri-Clamp Seals:</p> <table><tr><td>DN 32, EPDM</td><td>0314-596</td></tr><tr><td>DN 32, FPM</td><td>0314-597</td></tr><tr><td>DN 40, EPDM</td><td>0314-598</td></tr><tr><td>DN 40, FPM</td><td>0314-599</td></tr><tr><td>DN 50, EPDM</td><td>0314-590</td></tr><tr><td>DN 50, FPM</td><td>0314-591</td></tr></table> <p><small>** If using for eccentric screw pumps B70 an additional reducing piece DN 50 to DN 25/32/40 (Item 5) and a locking clamp (Item. 6) are required.</small></p>	Connection:	for hose with nominal diameter:	Seal:		Tri-Clamp DN 32**	DN 19 (3/4")	EPDM	0204-870	Tri-Clamp DN 32**	DN 19 (3/4")	FPM	0204-871	Tri-Clamp DN 32**	DN 25 (1")	EPDM	0204-872	Tri-Clamp DN 32**	DN 25 (1")	FPM	0204-873	Tri-Clamp DN 32**	DN 32 (1 1/4")	EPDM	0204-874	Tri-Clamp DN 32**	DN 32 (1 1/4")	FPM	0204-875	Tri-Clamp DN 32**	DN 38 (1 1/2")	EPDM	0204-876	Tri-Clamp DN 32**	DN 38 (1 1/2")	FPM	0204-877	Tri-Clamp DN 50	DN 38 (1 1/2")	EPDM	0172-746	Tri-Clamp DN 50	DN 38 (1 1/2")	FPM	0204-878	Tri-Clamp DN 50	DN 50 (2")	EPDM	0204-879	Tri-Clamp DN 50	DN 50 (2")	FPM	0204-880	DN 32 for hose DN 19	0370-093	DN 32 for hose DN 25	0370-094	DN 32 for hose DN 32	0370-095	DN 32 for hose DN 38	0370-096	DN 50 for hose DN 50	0370-097	DN 25/32/40	0370-088	DN 50	0370-084	DN 32, EPDM	0314-596	DN 32, FPM	0314-597	DN 40, EPDM	0314-598	DN 40, FPM	0314-599	DN 50, EPDM	0314-590	DN 50, FPM	0314-591	
Connection:	for hose with nominal diameter:	Seal:																																																																														
Tri-Clamp DN 32**	DN 19 (3/4")	EPDM	0204-870																																																																													
Tri-Clamp DN 32**	DN 19 (3/4")	FPM	0204-871																																																																													
Tri-Clamp DN 32**	DN 25 (1")	EPDM	0204-872																																																																													
Tri-Clamp DN 32**	DN 25 (1")	FPM	0204-873																																																																													
Tri-Clamp DN 32**	DN 32 (1 1/4")	EPDM	0204-874																																																																													
Tri-Clamp DN 32**	DN 32 (1 1/4")	FPM	0204-875																																																																													
Tri-Clamp DN 32**	DN 38 (1 1/2")	EPDM	0204-876																																																																													
Tri-Clamp DN 32**	DN 38 (1 1/2")	FPM	0204-877																																																																													
Tri-Clamp DN 50	DN 38 (1 1/2")	EPDM	0172-746																																																																													
Tri-Clamp DN 50	DN 38 (1 1/2")	FPM	0204-878																																																																													
Tri-Clamp DN 50	DN 50 (2")	EPDM	0204-879																																																																													
Tri-Clamp DN 50	DN 50 (2")	FPM	0204-880																																																																													
DN 32 for hose DN 19	0370-093																																																																															
DN 32 for hose DN 25	0370-094																																																																															
DN 32 for hose DN 32	0370-095																																																																															
DN 32 for hose DN 38	0370-096																																																																															
DN 50 for hose DN 50	0370-097																																																																															
DN 25/32/40	0370-088																																																																															
DN 50	0370-084																																																																															
DN 32, EPDM	0314-596																																																																															
DN 32, FPM	0314-597																																																																															
DN 40, EPDM	0314-598																																																																															
DN 40, FPM	0314-599																																																																															
DN 50, EPDM	0314-590																																																																															
DN 50, FPM	0314-591																																																																															
	<p>3 Adapter fitting Tri-Clamp</p> <table><tr><td>DN 32 on tube fitting DIN 11851 Rd 58 x 1/6 (DIN 405)</td><td>0172-668</td></tr><tr><td>DN 50 on tube fitting DIN 11851 Rd 78 x 1/6 (DIN 405)</td><td>0172-747</td></tr></table>	DN 32 on tube fitting DIN 11851 Rd 58 x 1/6 (DIN 405)	0172-668	DN 50 on tube fitting DIN 11851 Rd 78 x 1/6 (DIN 405)	0172-747																																																																											
DN 32 on tube fitting DIN 11851 Rd 58 x 1/6 (DIN 405)	0172-668																																																																															
DN 50 on tube fitting DIN 11851 Rd 78 x 1/6 (DIN 405)	0172-747																																																																															








Specification		Order-No.	Product detail
4	Hose connector with Tri-clamp		
	For connection of conductive hose onto the eccentric screw pump B70, discharge spout or Tri-Clamp armatures in explosive hazardous area. The hose connector ensures a highly conduction transition between conductive hose and pump/armature. The ohmic resistance between the armatures must be lower than 10 ⁶ Ohm. (Consisting of hose connector, clamp collars, locking clamp and seal) Material: Stainless steel (1.4404)		
	Connection:	for hose Nominal diameter:	Seal:
	Tri-Clamp DN 32**	DN 19 (3/4")	EPDM
	Tri-Clamp DN 32**	DN 19 (3/4")	FPM
	Tri-Clamp DN 32**	DN 25 (1")	EPDM
	Tri-Clamp DN 32**	DN 25 (1")	FPM
	Tri-Clamp DN 32**	DN 32 (1 1/4")	EPDM
	Tri-Clamp DN 32**	DN 32 (1 1/4")	FPM
	Tri-Clamp DN 40**	DN 38 (1 1/2")	EPDM
	Tri-Clamp DN 40**	DN 38 (1 1/2")	FPM
	Tri-Clamp DN 50	DN 50 (2")	EPDM
Tri-Clamp DN 50	DN 50 (2")	FPM	
For individual needs, e.g. for connection to on-site Tri-clamp armatures:			
Tri-clamp hose connector (1.4404):			
DN 32 for hose DN 19		0300-174	
DN 32 for hose DN 25		0300-175	
DN 32 for hose DN 32		0300-176	
DN 40 for hose DN 38		0300-177	
DN 50 for hose DN 50		0300-178	
Clamp collar (1.4408):			
DN 19		0300-180	
DN 25		0300-181	
DN 32		0300-182	
DN 38		0300-183	
DN 50		0300-184	
Tri-Clamp locking clamp (1.4408):			
DN 25/32/40		0370-088	
DN 50		0370-084	
Tri-Clamp Seals:			
DN 32, EPDM		0314-596	
DN 32, FPM		0314-597	
DN 40, EPDM		0314-598	
DN 40, FPM		0314-599	
DN 50, EPDM		0314-590	
DN 50, FPM		0314-591	
** If using for eccentric screw pumps B70 an additional reducing piece DN 50 to DN 25/32/40 (Item 5) and a locking clamp (Item. 6) are required.			

Accessories

For B70V SanitaryPlus and B70 PURE


Product detail	Specification	Order-No.
	5 Tri-Clamp reducing piece Suitable for connection of Tri-Clamp armatures DN 25/32/40 to a Tri-Clamp DN 50 connecting piece. Material: Stainless steel (1.4408) DN 50 onto DN 25/32/40	0300-185 ●
	6 Tri-Clamp locking clamp Suitable for connection of armatures DN 50 to a connecting piece DN 50. Material: Stainless steel (1.4408) incl. seal. DN 50, Seal EPDM DN 50, Seal FPM	0172-745 ● 0204-477 ●
	7 Discharge spout For mounting at the end of the hose for direct filling and transferring in containers incl. seal and clamp. Material: Stainless steel (1.4301/EPDM) Tri-Clamp DN 32 Tri-Clamp DN 40	0370-098 ● 0370-099 ●
	8 Discharge spout For mounting at the end of the hose for direct filling and transferring in containers incl. seal and clamp. Material: Stainless steel (1.4571, 1.4404/EPDM). Tri-Clamp DN 50	0172-748 ●
	22 Protection device for drum inliner For mounting onto the pump foot. Protects sensitive drum inliner and bags from damage. For pump tube B70V-H SanitaryPlus For pump tube B70V 120.1	0173-819 ● 0175-332
	11 Drum adapter in PP For fixing the eccentric screw pump B70 in the drum opening. For pump tube Ø 52-54 mm Universal for all current drum and bunghole openings	0208-056
	12 Clamping device SS (1.4571) To fasten the eccentric screw pump B70 in open-topped drums and containers. For pump tube Ø 52-54 mm	0205-052 ●
	13 Installation flange SS (1.4571) For fixing the eccentric screw pump B70 according to DIN 2573, DN 50, PN 6, to a companion flange. The flange is welded onto the pump tube. For pump tube Ø 52-54 mm	0170-310
	14 Wall bracket For safe storage of the eccentric screw pump B70 when not in use. for B70V for B70V-SR	0204-309 0204-307

● Suitable for transferring combustible and easy flammable liquids (e.g. ethanol, petrol) or in explosive hazard area.

Specification	Order-No.	Product detail
16 Balancer for eccentric screw pumps, with infinitely adjustable load balancer for easy lifting and moving of the pump Load bearing capacity: 18-22 kg Tackle: 2 m Load bearing capacity: 22-25 kg Tackle: 2 m Load bearing capacity: 25-30 kg Tackle: 2 m	0371-013 0371-014 0371-015	
17 Equipotential bonding cable Serves to create electrically conductive connection between explosion proof pump and container as earthing and equipotential bonding function. 2 m long with fastening clip 2 m long with two fastening clips for B70V-H Sanitary	0204-994 ● 0204-992 ●	
18 Ex-plug Ensures the safe mains connection of the pump in explosive hazardous areas. CEE round plug in accordance with EEx de IIC T6, splash proof in compliance with IP 65. 3-pole (alternating current) CEAG for B70V-SR (Ex) 3-pole (alternating current) STAHL for B70V-SR (Ex) 5-pole (three phase current) CEAG for B70V (Ex) 5-pole (three phase current) STAHL for B70V (Ex)	0336-536 ● 0336-540 ● 0336-537 ● 0336-541 ●	
19 Ex-socket Ensures the safe mains connection of the pump in explosive hazardous areas. CEE-socket in accordance with EEx de IIC T6, splash proof in compliance with IP 65. 3-pole (alternating current) CEAG for B70V-SR (Ex) 3-pole (alternating current) STAHL for B70V-SR (Ex) 5-pole (three phase current) CEAG for B70V (Ex) 5-pole (three phase current) STAHL for B70V (Ex)	0336-531 ● 0336-542 ● 0336-420 ● 0336-543 ●	
23 Motor protective switch for motor B70V (Ex) Explosion proof according to EEx de IIC T6 with thermal and electromagnetic trip, protection class IP 66. A lifting device and two cable protective coverings are necessary for the mounting. Ex, 1,6 - 2,5 A Ex, 2,5 - 4,0 A Ex, 4,0 - 6,3 A	0335-414 ● 0335-419 ● 0335-420 ●	
18 Coupling part, motor side When sourcing your own motor please order the correct coupling to suit the relative shaft diameter. Shaft diameter: Ø 14 mm Ø 19 mm Ø 24 mm Ø 28 mm (only in combination with intermediate flange) Intermediate flange for Ø 28 mm	0302-028 0302-027 0302-026 0302-029 0172-850	
19 Lifting device To simplify the process of lifting the pump in and out of drums or containers. When using an explosion proof driving motor the Ex-protective plug is mounted onto the lifting device. for pump tube HD-E for B70V-SR with universal motor	0155-154 0174-607	

Accessories

For PURE drum and container pumps



1 ● Hose

2 Hose clamp

3 Hose connection

4 ● Hose connector

8 Tri-Clamp locking clamp

9 Tri-Clamp seal

10 ● Nozzle

11 ● Drum adapter

12 ● Clamping device

13 Installation flange

14 Wall bracket

15 Lifting device

16 Balancer

17 ● Equipotential bonding cable

18 ● Ex-plug

19 ● Ex-socket



21 Flow meter

● Suitable for transferring combustible and easy flammable liquids (e.g. ethanol, petrol) or in explosive hazard area.




Specification	Order-No.	Product detail
<p>1 PVC spiral hose</p> <p>Hose for food liquids made of PVC with woven layer and embedded galvanized steel spiral, smooth interior and exterior, complies with EU Regulation 1935/2004 EG.</p> <p>Operating pressure: up to 14 bar Temperature of medium: -5 °C up to +65 °C Nominal diameter: Weight: DN 19 (3/4") 0,45 kg/m DN 25 (1") 0,67 kg/m DN 32 (1 1/4") 0,80 kg/m DN 38 (1 1/2") 1,15 kg/m</p>	<p>0374-466 0374-467 0374-468 0374-469</p>	
<p>1 Food chemical hose</p> <p>Colour coding: "blue/white/blue". Suitable for 95% of all customary industrial chemicals such as almost all acids and alkalis, mineral oil products and solvents of all kinds. Ideal for food and luxury foodstuffs, pharmaceuticals, cosmetics and hygiene products, complies with EU Regulation 1935/2004 EC and FDA and ATEX requirements. Foodstuff conformity of inner layer. Internal finish: UPE light with spiraled OHM conductive stripes UPE black, smooth, non-bleeding, abrasion-resistant. Intermediate layer: EPDM conductive External finish: EPDM light grey, conductive, non-bleeding, ozone- and UV resistant, hardly flammable, Type Ω/T smaller than 10⁶ Ohm (acc. to DIN EN 12115:2011).</p> <p>Operating pressure: up to 16 bar Temperature of medium: -30 up to +100 °C can be sterilized at 130°C for 30 minutes (open system)</p> <p>Nominal diameter: Weight: DN 19 (3/4") 0,6 kg/m DN 25 (1") 0,8 kg/m DN 32 (1 1/4") 0,9 kg/m DN 38 (1 1/2") 1,2 kg/m</p>	<p>0374-475 ● 0374-476 ● 0374-477 ● 0374-478 ●</p>	
<p>2 Stepless 1-ear hose clamp</p> <p>1-ear hose clamp of stainless steel for the safe fixing of different hoses onto the hose connection. (Advices for selecting the suitable hose clamp - see hoses).</p> <p>for Tri-Clamp 0204-870 / PVC spiral hose DN 19, fabric reinforced for Tri-Clamp 0204-870 / Food chemical hose DN 19</p> <p>for Tri-Clamp 0204-872 / PVC spiral hose DN 25, fabric reinforced for Tri-Clamp 0204-872 / Food chemical hose DN 25</p> <p>for Tri-Clamp 0204-874 / PVC spiral hose DN 32, fabric reinforced for Tri-Clamp 0204-874 / Food chemical hose DN 32</p>	<p>0300-417 0300-422 0300-446 0300-442 0300-453 0300-460</p>	

Accessories

For PURE drum and container pumps






Product detail	Specification	Order-No.																																																														
	<p>3 Hose connection with Tri-Clamp</p> <p>For connection of the hose onto the pump, nozzle or Tri-clamp armatures (consisting of hose connector, locking clamp and seal) Material: stainless steel (1.4404)</p> <table><tr><td>Connection:</td><td>for hose with nominal diameter:</td><td>Seal:</td><td></td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 19 (3/4")</td><td>EPDM</td><td>0204-870</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 19 (3/4")</td><td>FPM</td><td>0204-871</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 25 (1")</td><td>EPDM</td><td>0204-872</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 25 (1")</td><td>FPM</td><td>0204-873</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 32 (1 1/4")</td><td>EPDM</td><td>0204-874</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 32 (1 1/4")</td><td>FPM</td><td>0204-875</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 38 (1 1/2")</td><td>EPDM</td><td>0204-876</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 38 (1 1/2")</td><td>FPM</td><td>0204-877</td></tr></table> <p>For individual needs, e.g. for connection to on-site Tri-clamp armatures: Tri-clamp hose connector (1.4404):</p> <table><tr><td>DN 32 for hose DN 19</td><td>0370-093</td></tr><tr><td>DN 32 for hose DN 25</td><td>0370-094</td></tr><tr><td>DN 32 for hose DN 32</td><td>0370-095</td></tr><tr><td>DN 32 for hose DN 38</td><td>0370-096</td></tr></table> <p>Tri-clamp locking clamp (1.4408):</p> <table><tr><td>DN 25/32/40</td><td>0370-088</td></tr></table> <p>Tri-Clamp seals:</p> <table><tr><td>DN 32, EPDM</td><td>0314-596</td></tr><tr><td>DN 32, FPM</td><td>0314-597</td></tr><tr><td>DN 40, EPDM</td><td>0314-598</td></tr><tr><td>DN 40, FPM</td><td>0314-599</td></tr></table>	Connection:	for hose with nominal diameter:	Seal:		Tri-Clamp DN 32	DN 19 (3/4")	EPDM	0204-870	Tri-Clamp DN 32	DN 19 (3/4")	FPM	0204-871	Tri-Clamp DN 32	DN 25 (1")	EPDM	0204-872	Tri-Clamp DN 32	DN 25 (1")	FPM	0204-873	Tri-Clamp DN 32	DN 32 (1 1/4")	EPDM	0204-874	Tri-Clamp DN 32	DN 32 (1 1/4")	FPM	0204-875	Tri-Clamp DN 32	DN 38 (1 1/2")	EPDM	0204-876	Tri-Clamp DN 32	DN 38 (1 1/2")	FPM	0204-877	DN 32 for hose DN 19	0370-093	DN 32 for hose DN 25	0370-094	DN 32 for hose DN 32	0370-095	DN 32 for hose DN 38	0370-096	DN 25/32/40	0370-088	DN 32, EPDM	0314-596	DN 32, FPM	0314-597	DN 40, EPDM	0314-598	DN 40, FPM	0314-599									
Connection:	for hose with nominal diameter:	Seal:																																																														
Tri-Clamp DN 32	DN 19 (3/4")	EPDM	0204-870																																																													
Tri-Clamp DN 32	DN 19 (3/4")	FPM	0204-871																																																													
Tri-Clamp DN 32	DN 25 (1")	EPDM	0204-872																																																													
Tri-Clamp DN 32	DN 25 (1")	FPM	0204-873																																																													
Tri-Clamp DN 32	DN 32 (1 1/4")	EPDM	0204-874																																																													
Tri-Clamp DN 32	DN 32 (1 1/4")	FPM	0204-875																																																													
Tri-Clamp DN 32	DN 38 (1 1/2")	EPDM	0204-876																																																													
Tri-Clamp DN 32	DN 38 (1 1/2")	FPM	0204-877																																																													
DN 32 for hose DN 19	0370-093																																																															
DN 32 for hose DN 25	0370-094																																																															
DN 32 for hose DN 32	0370-095																																																															
DN 32 for hose DN 38	0370-096																																																															
DN 25/32/40	0370-088																																																															
DN 32, EPDM	0314-596																																																															
DN 32, FPM	0314-597																																																															
DN 40, EPDM	0314-598																																																															
DN 40, FPM	0314-599																																																															
<p>Caution: The assembler is responsible for the professional bonding of the hose according to the current Pressure Equipment Directive.</p>	<p>3 Adapter fitting Tri-Clamp</p> <p>DN 32 on tube fitting DIN 11851 Rd 58 x 1/6 (DIN 405)</p>	0172-668																																																														
	<p>4 Hose connector with Tri-clamp</p> <p>For connection of conductive hose onto the pump, nozzle or Tri-clamp armatures in explosive hazardous area. The hose connector ensures a highly conduction transition between conductive hose and pump/armature. The ohmic resistance between the armatures must be lower than 10⁶ Ohm. (Consisting of hose connector, clamp collars, locking clamp and seal). Material: stainless steel (1.4404)</p> <table><tr><td>Connection:</td><td>for hose with nominal diameter:</td><td>Seal:</td><td></td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 19 (3/4")</td><td>EPDM</td><td>0204-860 ●</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 19 (3/4")</td><td>FPM</td><td>0204-861 ●</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 25 (1")</td><td>EPDM</td><td>0204-862 ●</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 25 (1")</td><td>FPM</td><td>0204-863 ●</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 32 (1 1/4")</td><td>EPDM</td><td>0204-864 ●</td></tr><tr><td>Tri-Clamp DN 32</td><td>DN 32 (1 1/4")</td><td>FPM</td><td>0204-865 ●</td></tr><tr><td>Tri-Clamp DN 40**</td><td>DN 38 (1 1/2")</td><td>EPDM</td><td>0204-866 ●</td></tr><tr><td>Tri-Clamp DN 40**</td><td>DN 38 (1 1/2")</td><td>FPM</td><td>0204-867 ●</td></tr></table> <p>For individual needs, e.g. for connection to on-site Tri-clamp armatures: Tri-clamp hose connector (1.4404):</p> <table><tr><td>DN 32 for hose DN 19</td><td>0300-174</td></tr><tr><td>DN 32 for hose DN 25</td><td>0300-175</td></tr><tr><td>DN 32 for hose DN 32</td><td>0300-176</td></tr><tr><td>DN 40 for hose DN 38</td><td>0300-177</td></tr></table> <p>Clamp collar (1.4408):</p> <table><tr><td>DN 19</td><td>0300-180</td></tr><tr><td>DN 25</td><td>0300-181</td></tr><tr><td>DN 32</td><td>0300-182</td></tr><tr><td>DN 38</td><td>0300-183</td></tr></table> <p>Tri-Clamp locking clamp (1.4408):</p> <table><tr><td>DN 25/32/40</td><td>0370-088</td></tr></table> <p>Tri-Clamp Seals:</p> <table><tr><td>DN 32, EPDM</td><td>0314-596</td></tr><tr><td>DN 32, FPM</td><td>0314-597</td></tr><tr><td>DN 40, EPDM</td><td>0314-598</td></tr><tr><td>DN 40, FPM</td><td>0314-599</td></tr></table>	Connection:	for hose with nominal diameter:	Seal:		Tri-Clamp DN 32	DN 19 (3/4")	EPDM	0204-860 ●	Tri-Clamp DN 32	DN 19 (3/4")	FPM	0204-861 ●	Tri-Clamp DN 32	DN 25 (1")	EPDM	0204-862 ●	Tri-Clamp DN 32	DN 25 (1")	FPM	0204-863 ●	Tri-Clamp DN 32	DN 32 (1 1/4")	EPDM	0204-864 ●	Tri-Clamp DN 32	DN 32 (1 1/4")	FPM	0204-865 ●	Tri-Clamp DN 40**	DN 38 (1 1/2")	EPDM	0204-866 ●	Tri-Clamp DN 40**	DN 38 (1 1/2")	FPM	0204-867 ●	DN 32 for hose DN 19	0300-174	DN 32 for hose DN 25	0300-175	DN 32 for hose DN 32	0300-176	DN 40 for hose DN 38	0300-177	DN 19	0300-180	DN 25	0300-181	DN 32	0300-182	DN 38	0300-183	DN 25/32/40	0370-088	DN 32, EPDM	0314-596	DN 32, FPM	0314-597	DN 40, EPDM	0314-598	DN 40, FPM	0314-599	
Connection:	for hose with nominal diameter:	Seal:																																																														
Tri-Clamp DN 32	DN 19 (3/4")	EPDM	0204-860 ●																																																													
Tri-Clamp DN 32	DN 19 (3/4")	FPM	0204-861 ●																																																													
Tri-Clamp DN 32	DN 25 (1")	EPDM	0204-862 ●																																																													
Tri-Clamp DN 32	DN 25 (1")	FPM	0204-863 ●																																																													
Tri-Clamp DN 32	DN 32 (1 1/4")	EPDM	0204-864 ●																																																													
Tri-Clamp DN 32	DN 32 (1 1/4")	FPM	0204-865 ●																																																													
Tri-Clamp DN 40**	DN 38 (1 1/2")	EPDM	0204-866 ●																																																													
Tri-Clamp DN 40**	DN 38 (1 1/2")	FPM	0204-867 ●																																																													
DN 32 for hose DN 19	0300-174																																																															
DN 32 for hose DN 25	0300-175																																																															
DN 32 for hose DN 32	0300-176																																																															
DN 40 for hose DN 38	0300-177																																																															
DN 19	0300-180																																																															
DN 25	0300-181																																																															
DN 32	0300-182																																																															
DN 38	0300-183																																																															
DN 25/32/40	0370-088																																																															
DN 32, EPDM	0314-596																																																															
DN 32, FPM	0314-597																																																															
DN 40, EPDM	0314-598																																																															
DN 40, FPM	0314-599																																																															



● Suitable for transferring combustible and easy flammable liquids (e.g. ethanol, petrol) or in explosive hazard area.

Specification	Order-No.	Product detail
<p>10 Nozzle SS</p> <p>Ideally suitable for filling and transferring liquids – also for combustible and highly flammable liquids – in food and pharmaceutical industry. Stainless steel (1.4571) housing and valve tappet. With hoop guard and rotating joint.</p> <p>Operating pressure: up to 3 bar Viscosity: up to 760 mPas Flow rate: up to 50 l/min. (water) Temperature of medium: up to 80 °C Weight: approx. 1 kg Connection: Tri-Clamp DN 32 Seal: FPM or EPDM</p> <p>Basic price nozzle SS[▲] Additional price version: PURE FPM[▲] Additional price version: PURE EPDM[▲]</p> <p>[▲]Please choose Order-No. basic price nozzle + Order No. additional price version: PURE</p>	<p>0204-370 ● 0204-820 ● 0204-821 ●</p>	
<p>11 Drum adapter in PP</p> <p>For fixing the pump in the drum opening. For pump tube Ø 41 mm Outer thread G 2</p>	<p>0208-007</p>	
<p>11 Drum adapter in PE (electrically conductive)</p> <p>For fixing the pump in the drum opening. For pump tube Ø 41 mm Outer thread G 2 Outer thread BCS 56 x 4 Outer thread BCS 70 x 6</p>	<p>0208-055 ● 0208-052 ● 0208-054 ●</p>	
<p>12 Clamping device SS (1.4571)</p> <p>To fasten the drum pumps in open-topped drums and containers. For pump tube Ø 41 mm</p>	<p>0205-040 ●</p>	
<p>13 Installation flange SS (1.4571)</p> <p>For fixing the drum and container pump according to DIN 2573, DN 50, PN 6 to a companion flange. The flange is welded onto the pump tube. For pump tube Ø 41 mm</p>	<p>0151-622</p>	
<p>14 Wall bracket</p> <p>For safe storage of the pump when not in use.</p>	<p>0204-308</p>	

Accessories

For PURE drum and container pumps


Product detail	Specification	Order-No.
	<p>15 Lifting device To simplify the process of lifting the pump in and out of drums and containers.</p> <p>For pumps with motors MA II and ME II For pumps with motors B4/GT</p>	<p>0211-047 0214-196</p>
	<p>16 Balancer for drum pump, with infinitely adjustable load balancer for easy lifting and moving of the pump.</p> <p>Load bearing capacity: 10-14 kg Tackle: 2 m</p>	<p>0371-012</p>
	<p>17 Equipotential bonding cable Serves to create electrically conductive connection between explosion proof pump and container as earthing and equipotential bonding function.</p> <p>2 m long with fastening clip</p>	<p>0204-994 ●</p>
	<p>18 Ex-plug Ensures the safe mains connection of the pump in explosive hazardous areas. CEE round plug in accordance with EEx de IIC T6, splash proof in compliance with IP 65.</p> <p>3-pole (alternating current) system CEAG for motor ME II 3-pole (alternating current) system STAHL for motor ME II</p>	<p>0336-536 ● 0336-540 ●</p>
	<p>19 Ex-socket Ensures the safe mains connection of the pump in explosive hazardous areas. CEE-socket in accordance with EEx de IIC T6, splash proof in compliance with IP 65.</p> <p>3-pole (alternating current) system CEAG for motor ME II 3-pole (alternating current) system STAHL for motor ME II</p>	<p>0336-531 ● 0336-542 ●</p>

Specification	Order-No.	Product detail
<p>21 Modular electronic flow meter system, TS series, type VA10 in PURE version</p> <p>For measuring of liquid foodstuffs, pharmaceuticals and cosmetics. Wide application range: directly at the drum pump, decentralized or in-line operation possible. With touch screen display, multilingual menu and simple plain text operation. Also with volume preselection. (Suitable connecting parts see items 8 and 9)</p> <p>For more details see separate flow meter leaflet.</p>		
<p>8 Tri-Clamp locking clamp (1.4408)</p> <p>For fixing the flow meter VA10 PURE at the pump. (Suitable seal see item 9)</p> <p>DN 25/32/40</p>	<p>0370-088 ●</p>	
<p>9 Tri-Clamp seal</p> <p>For fixing the flow meter VA10 PURE at the pump.</p> <p>DN 32, EPDM DN 32, FPM DN 40, EPDM DN 40, FPM</p>	<p>0314-596 0314-597 0314-598 0314-599</p>	

Accessories

Contact-free indirect measurement



Product detail	Specification	Order-No.											
	<p>20 Lifting device with integrated impulse sensor Comprises of:</p> <p>Impulse sensor with connecting cable and 14-wire coupling plug, lifting device and flange plate. (Please order suitable impulse transmitter and control unit additionally)</p> <p>Additional price* for three-phase motors up to 1.1 kW</p> <p>Additional price* for three-phase motors up to 1.5 kW and explosion proof three-phase motors Ex</p> <p>Complete set for retrofitting available pumps</p> <p>*(Please indicate Ref. No. for additional price when ordering a pump)</p>	<p>0172-891</p> <p>0172-892 ●</p> <p>0172-890 ●</p>											
	<p>21 Impulse transmitter Must be ordered additionally suitable for the shaft diameter of the motor</p> <p>For shaft diameters:</p> <table><tr><td>Ø 19 mm</td><td>0172-824</td></tr><tr><td>Ø 20 mm</td><td>0172-825</td></tr><tr><td>Ø 24 mm</td><td>0172-826</td></tr><tr><td>Ø 25 mm</td><td>0172-827</td></tr><tr><td>Ø 28 mm</td><td>0172-828</td></tr><tr><td>Ø 30 mm</td><td>0172-829</td></tr></table>	Ø 19 mm	0172-824	Ø 20 mm	0172-825	Ø 24 mm	0172-826	Ø 25 mm	0172-827	Ø 28 mm	0172-828	Ø 30 mm	0172-829
Ø 19 mm	0172-824												
Ø 20 mm	0172-825												
Ø 24 mm	0172-826												
Ø 25 mm	0172-827												
Ø 28 mm	0172-828												
Ø 30 mm	0172-829												

● Suitable for transferring combustible and easy flammable liquids (e.g. ethanol, petrol) or in explosive hazard area.

Specification	Order-No.	Product detail
<p>23 Control unit With touch screen display and menu-navigated operation. Is intended for evaluation of impulses and display of flow volume, battery-operated**</p> <p>Control unit BE10 Control unit Ex BE10B</p> <p>Power supply unit NG10 230 V for external power supply of the operating unit 220-240 V, 50-60 Hz, II (2) G [Ex ib] IIC</p>	<p>0230-000 0230-010 ●</p> <p>0230-230</p>	
<p>Accessories optional</p> <p>Relay module RM30 For three-phase motors up to 1.5 kW allows the filling with pre-selection (batch function), 400 V, 1.5 kW, 50 Hz, II (2) G [Ex ib] IIC</p> <p>Power cable RM30 400V 400 V, 50 Hz, 5-wire, 5 m long</p> <p>Connecting cable motor RM30 400V 400 V, 50 Hz, 5-wire, 0.6 m long</p> <p>Relay module RM10 For three-phase motors with frequency converter allows the filling with pre-selection (batch function), 220-240 V, 50-60 Hz, II (2) G [Ex ib] IIC</p> <p>Power cable RM10 230V 230 V, 50 Hz, 5 m long</p> <p>Adapter cable motor RM-FU 230V/24V For three-phase motors with frequency converter 230V AC/24V DC</p>	<p>0230-220</p> <p>0211-388</p> <p>0211-386</p> <p>0230-200</p> <p>0211-155</p> <p>0230-323</p>	

** Limited battery operation without power supply unit possible

Twice the **COMPETENCE...**



Professional Fluid Management

Drum pump sets


Drum and container pumps

Eccentric screw drum pumps

Flow meter systems

Air operated double diaphragm pumps

Vertical and horizontal centrifugal pumps



Lutz Pumpen GmbH

P.O. Box 14 62 · D-97864 Wertheim · Phone: (+49 93 42) 8 79-0 · Fax: (+49 93 42) 87 94 04 · E-Mail: info@lutz-pumpen.de

www.lutz-pumpen.de

...simply **UNIQUE**



A Measured Step Forward



Dosing pumps and accessories


Chlorinators

Measuring and control technology

System and process technology

Chemical centrifugal pumps

Water disinfection





Lutz Pumpen GmbH

P.O. Box 14 62
D-97864 Wertheim
Phone: (0 93 42) 8 79-0
Fax: (0 93 42) 87 94 04
E-Mail: info@lutz-pumpen.de

www.lutz-pumpen.de